

# MIXX™

WORK



## Air Point

Optical Wireless Mouse

HOW TO GUIDE

# MIXX

W O R K

## THANKS!

Thank you for choosing to buy the MIXX Air Point Wireless Mouse.

All products brought to you by MIXX Limited come with a 2 year warranty for peace of mind.

Feedback is welcome, email us on [support@mixx-io.com](mailto:support@mixx-io.com) for any comments or queries.

We hope you enjoy using your new mouse.



# CONTENTS

LET'S START	1
LET'S CONNECT	2
LET'S USE THE MOUSE	3
LET'S BE SAFE	5
LET'S VIEW TECH SPECS	6
LET'S RECYCLE	6
CONTACT MIXX	6
SAFE USAGE INFO	X

# LET'S START

## What's in the box?

A MIXX Point Optical Wired Mouse



1 Left Button

2 Scroll Wheel

3 Right Button

4 DPI Button

5 Side Buttons

6 USB RF Receiver

7 Battery


8 Battery Slot

## LET'S CONNECT



Turn the mouse over and insert the battery (supplied) into the battery slot **8**.

Simply remove the USB RF Receiver **6** (supplied) by pushing the USB in and it will pop out of its slot. Then plug the USB receiver into the USB A port of your computer, laptop or notebook. You don't need to install any software for the mouse to work.



# LET'S USE THE MOUSE

## 2 Scroll Wheel

**Moving** the Scroll Wheel 2 **forward or back** with your finger allows you to scroll up and down any document you are viewing quicker than you would using the vertical scroll bar on the right your screen.

You can use the Scroll Wheel 2 as a third button, **click once** on the Scroll Wheel 2.

## 4 DPI Button

The DPI (Dot Per Inch) this is the speed of which the mouse moves on your screen in relation to you physically moving the mouse. It adjusts how sensitive the mouse is.

You can change the speed of the mouse's on-screen movements on the fly by simply pressing the up/down DPI Buttons 4 to set the required speed.

- 800 DPI (default)
- 1200 DPI
- 1600 DPI

## 5 Side Buttons

Use the pre-programmed Side Buttons 5 to go backwards or forward through web pages in a web browser.

## Hints for your workspace comfort

Assess your work space to ensure that both your mouse and keyboard are within easy reach and you are not over extending or excessively reaching so that it may cause discomfort to your body. If anything you are doing causes any discomfort then stop.

### Keep your mouse close

When using the mouse it is best that it is as close to you as possible. Suggest using a mouse mat with a wrist pad as this will avoid awkward bending and may help keep your wrist straight. If you're not using your keyboard, move it to the side and position the mouse closer to you.

### Have the keyboard straight in front of you

Place your keyboard in front of you when typing. Leave a gap of about 4 to 6 inches (100mm-150mm) at the front of the desk to rest your wrists between bouts of typing. Keep your arms bent in an L-shape and your elbows by your sides. Some people like to use a wrist rest to keep their wrists straight and at the same level as the keys.

### Take regular breaks

Preferably it is best not to sit in the same position for too long. Ensure you change your posture as often as is practicable. Frequent short breaks are better for your back than fewer long ones. It gives the muscles a chance to relax while others take the strain.

For more information see: [www.bit.ly/Workarea](http://www.bit.ly/Workarea)

## LET'S BE SAFE

It's important that you read this section completely, especially the **'Warning and Safe Usage'** instructions.

### For your protection

Ensure the product is correctly connected using the manufacturer's original accessories included with the product. Please keep the product out of reach from children and animals.

### We recommend

To refer all servicing to qualified persons. Servicing may be required when the product has been damaged in any way, does not operate normally or has been dropped. The operating temperature range for this product is 5° - 40° Celsius.

**WARNING:** Please avoid exposing the product and the cable connectors to prolonged rain, moisture, any splashing or liquid spills. This may cause excessive heat or melting and may lead to fire damage or personal injury.

## COMPATIBILITY


Compatibility with most computers, laptops or notebooks with a USB A port.



## LET'S VIEW TECHNICAL SPECS

<b>Mouse:</b>	Optical
Number of buttons:	6
Adjustable DPI:	800 - 1200 - 1600 DPI
Connection:	USB RF Receiver (supplied in mouse)

## LET'S RECYCLE

This product can be recycled. Products bearing this symbol  must NOT be thrown away with normal household waste. Take the product to a collection point designated for recycling of electronic devices. Find out more about return and collection point through your local authority.

## CONTACT MIXX

Feedback is welcome simply email us on [support@mixx-io.com](mailto:support@mixx-io.com) or visit [mixxwork.com](http://mixxwork.com) for more information.



# MIXX<sup>TM</sup>

CHARGE

To view our wide range of  
power banks, chargers, cables  
and in-car products visit

**[mixxcharge.com](http://mixxcharge.com)**

### SAFE USAGE INFO

Do not crush, puncture or incinerate the product or connector.

### INFORMATION DE SÉCURITÉ

Ne pas écraser, percer ou incinérer le produit ou le connecteur..

### INFORMATIONEN ZUR SICHEREN NUTZUNG

Brechen, durchstechen und verbrennen Sie das Produkt oder das Anschluss nicht.

# MIXX



[support@mixx-io.com](mailto:support@mixx-io.com)



[mixxwork.com](http://mixxwork.com)

MIXX Limited  
5 The Pavilions, Brighton Road, Pease Pottage,  
West Sussex, RH11 9BJ. United Kingdom

APNT-HTG01