



## PRIVACY

A lever/knob set that is locked/unlocked only from the inside by a turnpiece, push button, or privacy pin. Can be unlocked from the outside with the emergency release. Often used on bedroom and bathroom doors.