

remixd

TRULY WIRELESS EARBUDS QUICK START GUIDE



USB to Micro USB
Charging Cable

Pairing Quick Start Guide

Your truly wireless earbuds come pre-paired together and should pair to your phone like any other Bluetooth device once both earbuds are powered on. It is suggested you hold the earbuds close to your ears to hear the voice prompts.

1. Remove both earbuds from the case and hold down the power buttons for 3 seconds until you hear them say "Power On"
2. The earbuds should confirm they are paired together by playing "Left Channel" from the left bud and "Right Channel" from the right bud
3. Once these prompts play open your Bluetooth settings on your device and pair the "remixd Truly Wireless" device
4. If you are having issues please see the full user guide for troubleshooting.



Button functions

1. **Pause/play:** single press on either bud
2. **Track forward:** double press on host bud
3. **Answer/end call:** one press on host bud
4. **Reject call:** press and hold for 3-5 seconds on host bud
5. **Power On/Off:** press and hold for 3 seconds

remixd

TRULY WIRELESS EARBUDS

GUIDE DE DÉMARRAGE RAPIDE



Câble de Chargement
USB à Micro USB

Guide de jumelage rapide

Vos écouteurs réellement sans fil sont livrés pré-jumelés ensemble, et doivent être jumelés à votre téléphone comme tout autre appareil Bluetooth une fois les deux écouteurs allumés. Il vous est suggéré de maintenir les écouteurs proches de vos oreilles pour entendre les instructions vocales.

1. Retirez les deux écouteurs du boîtier et maintenez enfoncés les boutons marche pendant 3 secondes jusqu'à les entendre dire « Allumé »
2. Les écouteurs doivent confirmer qu'ils sont jumelés ensemble en jouant « Left Channel » dans l'écouteur gauche et « Right Channel » dans l'écouteur droit
3. Une fois ces instructions émises, ouvrez les paramètres Bluetooth de votre appareil et jumelez avec l'appareil « remixd Truly Wireless »
4. Si vous rencontrez des problèmes, veuillez consulter le guide d'utilisation complet pour le dépannage.



Fonctions des boutons

1. **Pause/Lecture** : pression unique sur l'un des deux écouteurs
2. **Piste suivante** : double pression sur l'écouteur hôte
3. **Répondre/terminer un appel** : pression unique sur l'écouteur hôte
4. **Rejeter un appel** : appuyer et maintenir enfoncé l'écouteur hôte pendant 3-5 secondes
5. **Allumer/Éteindre** : appuyer et maintenir enfoncé 3 secondes