



POST

Working parts of these fine releases are surface treated to incredible hardness that virtually eliminates wear at contact points. Due to the materials used, your Hot Shot release will function even more smoothly over time.



Adjusting trigger tension

Note: The set screw adjustment is very sensitive. We recommend no more than 1/8 turn of adjustment at a time.



While pushing on the jaw with your finger, turn the set screw slowly clockwise until the jaw opens. Then turn the set screw counter-clockwise 3/4 turn. This is the most sensitive setting that is safe to shoot.

WARNING - Turning the setscrew too far in the clockwise direction will cause the release to fire prematurely

To stiffen the trigger, turn the set screw counter-clockwise 1/8 of a turn at a time

After each adjustment, shoot your bow with the release. You will not feel any change except with shooting your bow.

Hot Shot Manufacturing
708 W 1800 N Ste 11A
Logan, UT 84321
(435) 752-9302
Fax (435) 752-9533

Email info@hotshotmanufacturing.com
www.HotShotManufacturing.com

CONGRATULATIONS on your purchase of a precision engineered & machined Hot Shot release! This is one of the finest products on the archery market today.

IMPETUS

Maintaining your Release

In order to keep your release working smoothly or if the trigger becomes sticky or does not move freely, we recommend you periodically:

1. Spray out your release using a gun scrubber or other cleaner that does not leave a residue.
2. Place a few drops of synthetic lubricant on the moving linkage areas.
3. Wipe off any excess oil.

Adjusting release length

1. Loosen hex screws approximately 1-1/2 turns.
2. Slide release post to desired length.
3. Tighten hex screws. **DO NOT OVER TIGHTEN** The lock washers will ensure the hex nuts do not become loose.

WARNING! Exercise extreme caution. Trigger tension can be set so that the release will "go off" prematurely while drawing the bow.

LIFETIME LIMITED WARRANTY

Every new Hot Shot release is guaranteed for the lifetime of the original purchaser against defects in materials and workmanship. For warranty service, the release must be returned to Hot Shot Mfg. Upon determination that the release is defective under this warranty, we will repair or replace it.

Normal wear, abrasion, misuse, abuse, alteration and disassembly of the release are not covered by warranty.

Lost parts are not covered by warranty. Replacement parts can be ordered by calling us or ordering them through our website.

Wrist straps & tether ribbons are not covered by warranty. We recommend replacing wrist straps annually.

To obtain warranty service, send your release to the Hot Shot Mfg address shown below. Shipping charges to us are not covered in this warranty. Include with the release your name and address, telephone number and a description of the problem.

