



NANO, CINCH

CONGRATULATIONS on your purchase of a precision engineered & machined Hot Shot release! This is one of the finest products on the archery market today.



NANO CINCH

Working parts of these fine releases are surface treated to incredible hardness that virtually eliminates wear at contact points. Due to the materials used, your Hot Shot release will function even more smoothly over time.

In order to keep your release working smoothly or if the trigger becomes sticky or does not move freely, we recommend you periodically:

1. Spray out your release using a gun scrubber or other cleaner that does not leave a residue.
2. Place a few drops of synthetic lubricant on the moving linkage areas.
3. Wipe off any excess oil.

WARNING! Failure to attach release properly to wrist strap could result in injury or bow damage.



Attaching release to wrist strap

1. Push tether ribbon through the eye on the release. Make tether ends even.
Note: Picture shows orientation of release to wrist strap for right-handed shooters.
2. Push both tether ribbon ends UP through the 1st wrist strap metal eye. Then push the ends DOWN through the 2nd eye, UP through the 3rd eye & DOWN through the 4th eye (UP, DOWN, UP, DOWN). Tighten the loops down snug & pull the ends out behind the wrist strap.

Adjusting length of release tether ribbon

- To shorten tether length, push both ribbons through the 1st eye nearest the release (away from the release) then through the other 3 eyes
- To lengthen tether length, push some ribbon through the eye farthest from the release (toward the release) then through the other 3 eyes

Adjusting trigger tension The release can be set to a "hair-trigger" setting or higher tension settings.



The factory setting for trigger tension is near "hair-trigger"

Using a 3/32 hex key, turn set screw clockwise to decrease tension (toward hair-trigger) & counter-clockwise to increase tension.

WARNING! Exercise extreme caution--trigger tension can be set so lightly that the release will "go off" prematurely while drawing the bow.

LIFETIME LIMITED WARRANTY

Every new Hot Shot release is guaranteed for the lifetime of the original purchaser against defects in materials and workmanship. For warranty service, the release must be returned to Hot Shot Mfg. Upon determination that the release is defective under this warranty, we will repair or replace it.

Normal wear, abrasion, misuse, abuse, alteration and disassembly of the release are not covered by warranty.

Lost parts are not covered by warranty. Replacement parts can be ordered by calling us or ordering them through our website.

Wrist straps & tether ribbons are not covered by warranty. We recommend replacing wrist straps annually.

To obtain warranty service, send your release to the Hot Shot Mfg address shown below. Shipping charges to us are not covered in this warranty. Include with the release your name and address, telephone number and a description of the problem.

Hot Shot Manufacturing
708 W 1800 N Ste 11A
Logan, UT 84321
(435) 752-9302
Fax (435) 752-9533

Email info@hotshotmanufacturing.com
www.HotShotManufacturing.com

