



VAPOR

Working parts of these fine releases are surface treated to incredible hardness that virtually eliminates wear at contact points. Due to the materials used, your Hot Shot release will function even more smoothly over time.

CONGRATULATIONS on your purchase of a precision engineered & machined Hot Shot release! This is one of the finest products on the archery market today.

VAPOR

No cocking. No release noise!
The thumb trigger is directly connected to the hook through an over-center mechanism. With no pressure on the hook, it opens when the trigger is pulled & closes when the trigger is let go. BUT once pressure is applied to the hook while drawing your bow, the hook does not move until release. You feel no trigger travel. Simply increase thumb pressure until release happens.
How much thumb pressure before release is fully adjustable. There is also a wide range of adjustments of thumb barrel position on the trigger.

Basic Use



Preparing to shoot:

1. Open hook by pulling on the thumb trigger

2. Place hook on string then release the trigger (hook closes by spring pressure)

Shooting:

Draw bow, aim &

3. Apply thumb **PRESSURE** until the hook releases.

Adjustments

The factory setting for trigger tension is near "hair-trigger"



1. Trigger tension.

Turn set screw clockwise to decrease tension (toward hair-trigger), counter-clockwise to increase tension.

2. Trigger thumb barrel fore-aft position.

- a. Loosen the 2 screws.
- b. Set desired fore-aft position.
- c. Tighten the 2 screws.

WARNING! Exercise extreme caution--trigger tension can be set so lightly that the release will "go off" prematurely while drawing the bow.

3. Trigger thumb barrel twist.

- a. Loosen the barrel set screw.
- b. Turn the thumb barrel to desired twist (barrel is on a threaded post).

4. Trigger thumb barrel up-down position.

- c. Turn thumb barrel clockwise to lower, counter clockwise to raise.
- d. Tighten set screw.

LIFETIME LIMITED WARRANTY

Every new Hot Shot release is guaranteed for the purchaser's lifetime against defects in materials and workmanship. For warranty service, the release must be returned to Hot Shot Mfg. Upon determination that the release is defective under this warranty, we will repair or replace it.

Normal wear, abrasion, misuse, abuse, alteration and disassembly of the release are not covered by warranty.

Lost parts are not covered by warranty. Replacement parts can be ordered by calling us or ordering them through our website.

Wrist straps & wrist lanyards are not covered by warranty.

To obtain warranty service, send your release to the Hot Shot Mfg address shown below. Shipping charges to us are not covered in this warranty. Include with the release your name and address, telephone number and a description of the problem.

Hot Shot Manufacturing

708 W 1800 N Ste 11A

Logan, UT 84321

(435) 752-9302

Fax (435) 752-9533

Email info@hotshotmanufacturing.com

www.HotShotManufacturing.com

