

AILINKE

ALK-MH-IN01

User's Guide

With Warranty Card

Thanks for your purchase.
We provide a one-year warranty.
If any quality issues, replacement or refund is available.
Please feel free to contact us via E-mail:

service@keecoon.com



Precautions

Thank you for purchasing our humidifier **ALK-MH-IN01**.
Please read this manual carefully before using
and keep it for future reference.

All pictures shown are for illustration purposes only.
Actual products may vary due to product enhancement.

***The pure water bottle container is not included.**

Contents

Safety Guide	1-2
Components	3
Usage Occasions	4
Installation	5-6
Control Panel & Remote Control	7
Maintenance	8
FAQ	9-10
Product Specifications	11
Warranty Card	12-13





Safety Guide

- ❶ Please do not disassemble or transform the machine.
- ❷ Please do not let the machine be strongly impacted.
- ❸ Please stop the machine before moving it.
- ❹ Please don't connect the socket that exceeds the rated voltage and don't use the extension cable, so as to avoid fire or electric shock.
- ❺ When the plug or wire is abnormally hot, please stop using it.
- ❻ Please do not use wet hands to pull out the power plug, otherwise it may cause electric shock or injury.
- ❼ Please do not block the outlet or add water from the mist outlet otherwise it may cause water leakage, machine deformation or failure.
- ❽ Please do not use acidic detergent in the main body. If there is residual detergent, it may produce toxic gas.
- ❾ Children should use it under the supervision of adults.
- ❿ Please do not deliberately inhale the spraying mist, especially for people with the sensitive respiratory tract.

Safety Guide

- ❶ Please do not add obvious acid and alkaline additives to the main body, such as essential oils, otherwise, the lifetime of the product will be shortened. For special purposes, neutral additives can be added to the bucket.
- ❷ Please do not insert your fingers or other things into the water inlet or air outlet or the gap of the machine which may cause damage to the machine or electric shock.
- ❸ When not in use for a long time (more than 24 hours), please pour out the water in the main body to prevent mold or impurities from damaging your health.

Components



Usage Occasions

Thanks to the creatively portable design, you can use it wherever you need, like commercial & industrial occasions such as office, warehouse, indoor growing plant! Once you fix it tightly, it will constantly add moisture to the air amazingly.

The diameter of the adaptive bucket / water tank is 1.96 inch / 5cm. Here are some samples of the water bottle container that compatibled with the humidifier.



Installation



1. Take out the main body and accessories from the box.



2. Attach the mist nozzle, mist tube and mist tube connection.



3. Attach the tube to the filter element and the water inlet under the main body.

Installation



4. Place the filter element connected to the tube into the water bucket.




5. Turn on the power. You need to wait 40-60s for the first use to produce mist.




- ❗ When the water is insufficient, the machine will prompt for water shortage and automatically shut down.
- ❗ Please do not add obvious acid and alkaline additives to the main body, such as essential oils, otherwise, the lifetime of the product will be shortened. For special purposes, neutral additives can be added to the bucket.
- ❗ The opening size of the matching bucket is about 5cm







Control Panel & Remote Control



Display & Buttons



Remote Control

 POWER	<p>Touch the power button, the display lights up and the humidifier starts to work.</p>
 HUMIDITY	<p>The humidity setting range is 40-90%, and each touch increases by 5%. The humidifier will automatically stop spraying mist when the surrounding humidity reaches the set value.</p>
 TIMER	<p>The timer can be set for 1, 2, 4, 8 hours. The humidifier will shut down automatically when the time reaches the set value.</p>
 MAX-MIN	<p>The mist volume can be adjusted in three levels: low, medium, high.</p>
 UV	<p>Long touch the "TIMER" button to turn on/off the UV function. A purple light in the water sink will appear when turning it on.</p>
 SLEEP	<p>Long touch the "HUMIDITY" button to turn on the sleep function and turn off the display automatically. Touch any button to exit and the display will light up.</p>

- ❶ The operation of remote control is the same as the control panel.
- ❷ Please remove the insulating plastic sheet before using the remote control.
- ❸ When turning on the UV light, do not look directly for a long time, otherwise it may cause eye discomfort.

Maintenance



Detach the accessories and take off the cover.



Tilt the main body to this side and pour out the water. Take care not to wet the ground.



Wipe the inside of the machine with the sponge monthly.

- ❶ When not in use for a long time (more than 24 hours), please pour out the water in the main body to prevent mold or impurities from damaging your health.
- ❶ Be sure to pull out the power plug before maintaining the humidifier.
- ❶ Do not directly flush the whole machine with water to avoid short circuits and failure.
- ❶ With the use of tap water, minerals and organics may adhere to it, which may cause the function of the humidifier to decline or malfunction. If the dirt is not easy to clean, the cloth can be soaked in neutral detergent before wiping.
- ❶ The residue of detergent in the sink and tank should be cleaned up before use.
- ❶ Make sure the main body is completely dry before use.

FAQ

Q: After the power is turned on, the display does not light up.

A: There may be water entering the circuit board. Please air-dry the main body for one day. If it still can't be turned on, please contact customer service by email.

Q: Low mist output.

A: When the ambient humidity exceeds the set value, the machine will stop spraying mist automatically. But if the atomizer is damaged, please contact customer service by email.

Q: Red light flashing.

A: Please open the sink and check whether the water can be pumped up. If not, check whether the water pipe has fallen or broken. None of the above, contact customer service by email.

Q: Abnormal noise.

A: There is too little water in the tank, or the ground is not stable. Please fill water and place the humidifier on a flat and stable surface.

Q: The humidity value is not completely consistent with the room humidity.

A: Please keep the humidity sensor from blocking and wetting. The difference of 5-10 degrees is in the normal range. If not, please contact customer service by email.

FAQ

Q: There is white powder around the humidifier.

A: Tap water contains certain minerals, may adhere to the object, please do not worry and clean the water tank regularly. Keep the precision instrument away from the humidifier to avoid damage to them.

Q: There is scale in the water sink or tank.

A: Tap water contains certain minerals, may adhere to the object, please do not worry and clean the water sink and tank regularly.

Q: Interference with TV remote control signal.

A: Keep the humidifier 1m away from the TV or other objects that emit radio waves.

Q: The floor is wet or there is water around the humidifier.

A: Humidity is too high, or the humidifier is placed in a non-ventilated place, so the mist can not be fully evaporated.

Q: The fire on the stove turned red.

A: Because the composition of the tap water reacts with the flame(Flame reaction), please keep the humidifier away from the stove.

Product Specifications

Product Name	Ultrasonic Humidifier
Model Number	ALK-MH-IN01
Operation Mode	Low Medium High
Max Mist Output	800mL/h
Rated Power	53W
Noise	≤35dB
Size	(W)273mm × (D)273mm × (H)600mm
N.W.	2.2Kg
G.W.	3.2Kg
Safety Functions	1, 2, 4, 8 hours timer
	Waterless auto shut-off
	Automatic shutdown when falling



Warranty Card

Model Number	ALK-MH-IN01
Warranty Period	Within 1 year from the date of purchase
Purchase date	Year Month Date
Customer	Name
	Address
	Phone Number
Store	

Warranty Period

- ① Our company provides a one-year warranty, which starts from the date of purchase.
- ① When returning the product, please confirm that the product is intact, and the packing boxes and accessories are complete.

Non-Warranty Policy

The following conditions are not covered by the warranty.

- ① Over the warranty period.
- ① Damage caused by natural disasters and other force majeure.
- ① Any damage caused by use not in accordance with the requirements in the User Manual.
- ① Failure or damage caused by forced use of the product.
- ① The user disassembles or repairs the product without authorization.

Warranty Requirements

1. Please provide the warranty card and the order number.
2. Please describe the problems in details with pictures or videos.
3. Send e-mail to service@keecoon.com

Sorry that warrant service would not be available if you are unable to provide the above information.

AILINKE