



@Oxilam Lighting



Warning

1. Fully charged before using for the first time.
2. This product was desinged for 12V lead acid/AGM/Gel batteries/ vehicles ONLY.
3. Never short-circuit the jump starter by connecting the RED and BLACK clamps.
4. Do not disassemble the jump starter.
5. Do not use it as a toy for Chirdren.
6. Store in a dry place, do not expose to damp conditions or near corrosive materials.
7. If the jump starter expands, leakage or peculiar smell is found, stop use immediately.
8. Please use this jump starter at normal temperature and be far away from too wet, too hot and fire.
9. "DO NOT jump start the car engine more than 3 times continuously as it may overheat or damage the product", there should be an interval of 60 seconds between each jump start.
10. When the battery power of the unit is less than 20%, do not use the jump starter as it will damage the unit.
11. Recharge the unit every 3 months to prevent from being over-discharged.
12. After starting the car, please wait at least 30 minutes before charging the product.
13. Be sure to use the standard jumper cable that comes with the product to start the vehicle.

How To Get A Warranty Honored?

1. We offer 24 months warranty on products, please feel free to contact us through amazon message or email us to service@oxilam.com.
2. If you have checked the Questions & Answers and confirm product failed, please kindly follow the below steps to get the warranty faster.


Steps to Get Warranty

1. Take some photos to show the problem you meet.
2. Send the photos to us and describe the problem detail in the email or Amazon message.
3. We will help you solve the problem or arrange the replacement for you after checking the photos.

Note:


1. As a result of operational errors caused by damage to the product, no warranty.
2. After the unauthorized disassemble, no warranty.

OXILAM




Y1 Multi-Function Car Jump Starter
USER MANUAL

Accessories and Functions



- ① ON/OFF
- ② Power Button
- ③ Power Indicator Light
- ④ Car Starting Port
- ⑤ Output 2
- ⑥ Output 1
- ⑦ Input
- ⑧ LED Light (Product back)

Spare Parts List



Technical Specifications

Model	Y1
Capacity	26.64Wh
Input	5V/2A
Output 1	5V/2.1A
Output 2	5V/1A
Operating Temperature Protections	Short circuit proof, over charge protection and discharge protection

Operation Instruction

1. How to start vehicle when battery is flat?


1. Plug the smart cable clamp into the jump starter.
2. Connect the smart cable clamp to the car battery (Red is positive and Black is negative).
3. Start your vehicle engine.
4. After the car has been started, remove the plug from the jump starter and remove the clamps from the car battery.

2. How to charge a mobile phone or digital products?

1. Plug the USB port of the charging cable into the product USB Interface. Inset the other side into the input port of the mobile phone.
 2. Flip ON/OFF
 3. Press the power button to charge it.
- *The machine has output short-circuit protection function: the output is automatically turned off when short-circuited (after the fault is removed, it needs to be restored by pressing the button or activated by charging).

Operation Instruction

3. How can led emergency light be turned on?



4. How to recharge the product?

1. Insert the charging cable.
2. Connect the charging cable to a USB port to recharge the product.

Exemption of Warranty

1. The company undertake no responsibility for any problems caused by incorrect operation.
2. After the unauthorized disassemble, company does not undertake any responsibility.
3. The problem caused by wrong charger does not match the product, company does not undertake any responsibility.
4. Beyond the shelf life of products, company does not undertake any responsibility.