


Equity

**NightVision ALARM CLOCK
MODEL 21103**

OPERATING INSTRUCTIONS

Please read these instructions carefully and keep in a safe place for future reference.



FEATURES:

1. Crescendo alarm.
2. Repeating snooze alarm.
3. Blue superbright backlight.

TO ACTIVATE THE CLOCK

Open the battery cover (at the bottom of the clock) and insert 3xAA batteries observing the indicated polarity symbols. Replace the cover.

TO SET THE TIME

Turn the 'Time setting knob' in the direction of the arrow to set the hour and minute hands to the correct time.

TO SET THE ALARM TIME

Turn the 'Alarm setting knob' in the direction of the arrow to the desired wake up time.

TO ACTIVATE/DEACTIVATE THE ALARM

Slide the 'Alarm ON/OFF switch' to AL.ON position to activate the alarm. To deactivate the alarm, slide the 'Alarm ON/OFF switch' to the AL.OFF position.

TO USE THE SNOOZE

When the alarm sounds, press the 'Snooze/Light button' to stop the alarm. The alarm will sound again after 5 minutes. The snooze feature can be repeated until the 'Alarm ON/OFF switch' is turned OFF.

www.equitybylacrosse.com/support

NightVision Operating Instructions:

This clock incorporates NightVision® Technology. To Activate the NightVision sensor, slide the backlight switch to the "Sensor" position. This cordless battery operated feature allows you to see the time in a dark room. When light level is extremely low, the light sensor automatically illuminates a dim glow behind the dial. When your eyes adjust in a darkened room, you can see the time! The sensor automatically turns off the NightVision® glow when the room brightens. To turn the backlight on all the time, slide the backlight switch to the "ALWAYS ON" position. Turning the backlight on all the time will reduce battery life.

CHANGING THE BATTERIES

- It is recommended that you replace the batteries annually, even if the product is still running.
- Do not mix old and new batteries, Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.)
- Only use AA (1.5V) Alkaline batteries in this clock.
- Please dispose of used batteries in a responsible manner.

MAINTENANCE

A soft cloth may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

You can activate a bright backlight display anytime by pressing the snooze/light bar.

Two Year Warranty:

Equity products are warranted for two years from the date of consumer purchase against defects on material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's option, without charge. This warranty does not cover damage caused by misuse or negligence. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD OF TWO YEARS FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your clock is not working, send it with a letter explaining the problem and \$5.00 for postage and handling to:

Equity by La Crosse.

Warranty Department.

2830 26th St. S.

La Crosse, WI 54601



Please help in preservation of the environment and return used batteries to an authorized depot. Remove the battery from the clock if you do not intend to use for an extended period of time.

Made in China

Printed in China

www.equitybylacrosse.com/support