


Quartz Clock Model 25011/25012/25013/25014/25015/24400 Operating Manual



Battery: Insert one new AA Alkaline battery according to the polarity marked in the battery compartment.

Time Set: Turn the time set knob to the desired time.

This clock will be accurate to within a few minutes per year. Should the timekeeping suddenly fluctuate, replace the battery

Two Year Warranty (U. S. A)

Equity products are warranted for two years from the date of consumer purchase against defects in material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's option, without charge. This warranty does not cover damage caused by misuse or negligence. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD ENDING FROM ONE YEAR FROM DATE OF PURCHASE. Some states do not allow limitations on how long an implied warran ty will last so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State. Return of warranty card is not a condition precedent to warranty coverage and performance.

If your clock isn't working, send it with a letter explaining the problem and \$5.00 for Postage and handling to :

Equity Warranty Dept., 2817 Losey Blvd. So. La Crosse WI 54601.



Please help in preservation of the environment and return used batteries to an authorized depot.Remove the battery from the clock if you do not intend to use for an extended period of time

