

OPERATING INSTRUCTIONS MODEL# 27001/27002/27006

To START CLOCK

- 1.Remove the battery cover from the back of the clock.
- 2.Insert one (1) "AA" battery (not included) according to the polarity indicators (+/-) inside the battery compartment.Replace the battery cover.

To SET TIME:

Turn the time set knob at the back of clock clockwise to the desired time.

To SET ALARM:

- Turn the alarm set knob at the back of the clock counterclockwise to desired alarm time.
- 2.Slide the alarm switch to the "ON" position.
- 3. When the alarm sounds, slide the alarm switch to the "OFF" position to deactivate the alarm.

SNOOZE & LIGHT OPERATION:

- 1.Press the button on the front side of the clock case to activate the snooze and light.
- 2.The alarm will sound again in 5 minutes.

NOTE

This clock should be accurate to within a few minutes a year. Should the timekeeping suddenly fluctuate replace the battery.

Always purchase the correct size and grade of battery most suitable for the intended use. Clean the battery contacts and also those of the device prior to battery installation. Ensure the battery is installed correctly with regard to polarity (+and-). Remove used battery from equipment when it is not to be used for an extended period of time. Remove used battery promptly. Please help in preservation of the environment and return used battery to an authorized depot. Replace all batteries of a set at the same time.

Two Year Warranty (U.S.A.)

Equity products are warranted for two years from the date of consumer purchase against defects in material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's option. This warranty does not cover damage caused by misuse or negligence. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD ENDING TWO YEARS FROM DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your product is not working properly, please send:

- -the product
- -a letter explaining the problem
- -and \$5.00 for postage and handling to:

Equity by La Crosse Warranty Department 2830 26th St. S. La Crosse, WI 54601

Made in China

Printed in China

www.equitybylacrosse.com/support