

Elgin QUARTZ BEDSIDE ALARM CLOCK

OPERATING INSTRUCTIONS


MODELS 3650E / 3652E / 3655E

FEATURE

1. Lighted dial on demand
2. Loud twin-bell alarm
3. Repeating snooze
4. Accurate quartz movement
5. Requires one (1) "C" size battery (not included)
6. One (1) year limited warranty

BATTERY

This clock operates on one "C" size battery. To install the battery, remove the battery door located on the back of the clock, and insert the battery as indicated by the polarity symbols (+/-) marked on the inside of the battery compartment. Once completed, put the battery door back on. If the clock does not activate after inserting the battery, check to make sure the battery is fresh and properly installed.



If the clock does not operate, or steadily loses time, or if the alarm sound is weak, the battery is low and should be replaced.

SETTING THE TIME

To set the time, turn knob (A) in the direction of the arrow to set the hour and minute hands to the correct time.

SETTING THE ALARM TIME

To set the alarm, turn knob (C) in the direction of the arrow until the alarm hand is set to the desired time on the dial. To activate the alarm, slide the alarm switch (B) to the "ON" position.

SNOOZE

The Snooze / Light button (E) is located in the base of the clock. The alarm can be stopped and repeated again four (4) minutes later when the top of the clock is pressed.

This snooze function can be repeated again and again. To stop the alarm / snooze, slide the alarm switch (B) to the "OFF" position.

LIGHTED DIAL

The dial can be illuminated at any time by pressing the top of the clock.