


18" Indoor/outdoor Lighted Dial Clock




Setup

1. Insert 4 "D" batteries into the 2 battery compartments, for the lighted dial.
2. Turn the switch to ON.
3. Insert 1 "AA" battery into the movement.
4. Always observe the polarity markings when inserting batteries.
5. Rotate the Time Set Wheel to set the time.
6. Mount on the wall and enjoy!

Lighted Dial

- When switch is ON, the clock illuminates when dark, for up to 6 hours.
- The light timer will reset once clock is exposed to light.
- If the switch is OFF the clock will not illuminate.



Frequently Asked Questions

Q: Will this clock provide times around the world?

A: The time is set manually. The clock may be set for any time around the world.

Q: Why do the hands spin?

A: Hands may spin if the battery is under powered or over powered. Use only Alkaline batteries in the clock.

Limited Warranty

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of 2 years from the date of sale to the customer. Warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock Company
Warranty Department
2830 South 26th Street.
La Crosse, WI 54601
www.lacrosseclock.com/support



Specifications

Power Requirements: 4 "D" LR20 Alkaline Batteries (lighted dial)
1 "AA" LR6 Alkaline Battery (clock)

Battery Life: over 12 months

Care and Maintenance

- Always purchase the correct size and grade of batteries most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Promptly remove expired batteries.
- The specs of this wall clock may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.

Made in China – Printed in China

www.lacrosseclock.com/support