

## WARRANTY & SUPPORT

La Crosse McCormick, LLC provides a 2-year limited warranty on this product against manufacturing defects in materials and workmanship. Under the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery. Send the clock (postage prepaid) with the date and proof of purchase to the following address. Please include the product model number and your complete address and phone number.

La Crosse Clock Company  
Warranty Department  
2830 South 26<sup>th</sup> Street.  
La Crosse, WI 54601

For Online support visit: [www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)  
Patents: [www.lacrossetechnology.com/pages/patents](http://www.lacrossetechnology.com/pages/patents)

## STAY IN TOUCH

Ask questions, watch set up videos, and provide feedback on our social media outlets. Follow La Crosse Technology on Youtube, Facebook, Instagram, and X (Twitter).



**⚠ WARNING:** This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

Made in China - Printed in China

LA CROSSE  
CLOCK CO.

## 15.16 - Inch Moving Gears Wall Clock



Model: 404-3439

DC: 060624

## POWER UP

1. Pull up on the OPEN end of the Battery Cover and slide off to reveal the battery compartments.
2. Insert 1 fresh AA alkaline battery, according to polarity, into the Movement.
3. Rotate the Time Set Wheel to set the time.
4. Insert 3 fresh AA alkaline batteries, according to polarity, to operate the moving gears.
4. Mount on a wall and enjoy!


Learn more from our video:  
[bit.ly/wallclock\\_setup](https://bit.ly/wallclock_setup)

**Note:** The quartz movement will keep the clock running accurately. If the clock does not operate, or steadily loses time, replace the battery in the movement

## MOUNTING

Use the Hanger Hole on the back to mount the clock.

For Moving Gears



## SPECIFICATIONS

- **Movement:** Quartz – Step Motion
- **Lens Type:** Glass
- **Construction:** Metal, Glass
- **Placement:** Indoor
- **Mounting Type:** Wall Mount
- **Numerals:** Arabic (1-12)
- **Power Requirements:** 1 “AA” Alkaline Battery (Not Included)
- **Optional Moving Gears:** 3 AA (IEC, LR6, 1.5V) batteries (Not included) into the Moving Gear compartment.
- **Battery Life:** 12+ Months for the movement
- **Dimensions:** 15.16 in (38.50cm) Diameter 2.55 in (6.5cm) Deep

## CARE & MAINTENANCE

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.