Warranty & Support

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of 2 years from the date of sale to the customer. Warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock Company Warranty Department 2830 South 26th Street. La Crosse, WI 54601

www.lacrossetechnology.com/support

▲ WARNING: This product can expose you to chemicals including styrene, which is known in the State of California to cause cancer. For more information go to: https://www.p65warnings.ca.gov/




18-Inch Louisa Wall Clock



Model: 404-3846 DC: 072119

Power Up

- Insert 1 fresh AA, LR6 1.5 volt alkaline battery according to the polarity markings. The battery is a snug fit.
- 2. Rotate the Time Set Wheel to set the time.
- 3. Mount on your wall and enjoy!



Note: The quartz movement will keep the clock running accurately. If the clock does not operate, or steadily loses time, replace the battery.

Specifications

- Battery Requirements: 1 AA (IEC LR6) required in the movement (Alkaline recommended)
- Battery Life: 12 months

Care & Maintenance

- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of your clock prior to battery installation.
- Ensure the battery is installed with correct polarity (+ and -).
- Remove battery from equipment when it is not used for an extended period of time.
- Promptly remove an expired battery.
- The specs of this wall clock may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.