

LA CROSSE CLOCK CO.


23.5" Decorative Analog Wall Clock



Model: 404-3960W
DC: 100617

Get Started

1. Insert 1 AA battery into the movement in the center of your clock.
2. Spin the time set wheel to set the time.
3. Mount on the wall and enjoy your clock.



Note: The quartz movement will keep your clock running accurately. If your clock does not operate, or steadily loses time, replace the battery.

Position Clock

Mount your clock on a wall with the hanging hole on the back of your clock.

Specifications

Battery Requirements: 1 AA (IEC LR6) required in movement (Alkaline recommended)

Battery life: 1 battery; over 12 months

Let's Get Social

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media channels!



Care and Maintenance

- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed with correct polarity (+ and -).
- Remove battery from equipment that is not to be used for an extended period of time.
- Promptly remove expired battery.

Limited Warranty Information

La Crosse McCormick, LLC. provides a 2-year limited warranty (from the date of the original consumer purchase), on this product against manufacturing defects in materials and workmanship. Send \$10.00 with date and proof of purchase to the following address. Please include the model number of your product and your complete address and phone number.

La Crosse McCormick, Warranty Department, 2830 S. 26th St., La Crosse, WI 54601

www.lacrossetechnology.com/support