

# LA CROSSE CLOCK CO.


## 23.5" Decorative Analog Wall Clock



Model: 404-4060  
DC: 022817

## Get Started

1. Insert 1 AA battery into the movement in the center of the clock.
2. Spin the time set wheel to set the time.
3. Mount on the wall and enjoy your clock.



**Note:** The quartz movement will keep the clock running accurately. If the clock does not operate, or steadily loses time, replace the battery.

## Position Clock

Mount the clock on a wall with the hanging hole on the back of the clock.

# Specifications

**Battery Requirements:** 1 AA (IEC LR6) required in movement (Alkaline recommended)

**Battery life:** 1 battery; over 12 months

## Visit Us on Social Media



[http://bit.ly/LaxTech\\_YouTube](http://bit.ly/LaxTech_YouTube)



[http://bit.ly/LaxTech\\_Facebook](http://bit.ly/LaxTech_Facebook)



[http://bit.ly/LaxTech\\_Twitter](http://bit.ly/LaxTech_Twitter)



[http://bit.ly/LaxTech\\_Pinterest](http://bit.ly/LaxTech_Pinterest)

## Care and Maintenance

- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed with correct polarity (+ and -).
- Remove battery from equipment that is not to be used for an extended period of time.
- Promptly remove expired battery.

## Limited Warranty Information

La Crosse McCormick, LLC. provides a 2-year limited warranty (from the date of the original consumer purchase), on this product against manufacturing defects in materials and workmanship. Send \$5.00 with date and proof of purchase to the following address. Please include the model number of your product and your complete address and phone number.

La Crosse McCormick, Warranty Department, 2830 S. 26th St., La Crosse, WI 54601

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)