

ATOMIC DIGITAL CLOCK




MODEL: 513-1211
DC: 013124


Find more product information and support here: bit.ly/laxtech_support

POWER UP

1. Insert 3-AA batteries into your Atomic Clock.
2. Complete Basic Settings.



WWVB ATOMIC TIME SIGNAL

- After an initial search, the clock will automatically search for the WWVB Atomic Time Signal at UTC 7:00, 8:00, 9:00, 10:00, and 11:00.
- The Atomic Time Signal Icon  will flash while searching, and be solid when connected.
- Hold the **WAVE/+** button anytime, to manually search for the Atomic Time Signal.

For information about WWVB Atomic Time visit: bit.ly/AtomicTime

SETTINGS

1. Hold the **SET** button to enter the Settings Menu.
2. Press the **WAVE/+** or **DST/-** button to adjust values.
3. Press the **SET** button to confirm and move to next item.

Settings Menu Order:

- 12/24 Hour
- Hour
- Minutes
- Year
- Month
- Date
- Fahrenheit/Celsius

Note: Weekday will set automatically when Year, Month and Date are set.

TIME ZONE

- Slide the Time Zone Switch on the back to your correct time zone: EST = Eastern, CST = Central, MST = Mountain, PST = Pacific

DAYLIGHT SAVING TIME INDICATOR

- Hold the **DST** button to activate or deactivate the DST Indicator.
- The letters DST will show above the seconds to indicate the indicator is on, and the clock will automatically change for Daylight Saving Time.

FAHRENHEIT OR CELSIUS


- Hold the °C/°F button to select Fahrenheit or Celsius temperature display.

TIME ALARM

Set Alarm Time:

1. Press the **SET** button to view Alarm Time. “AL” will show.
2. While viewing alarm time, hold the **SET** button to enter the Alarm Settings.
3. Press the **WAVE/+** or **DST/-** button to adjust values.
4. Press the **SET** button to confirm and exit.

Activate/Deactivate Alarm:

1. Press the **SET** button to view Alarm Time. “AL” will show.
2. Press the **WAVE/+** or **DST/-** button activate or deactivate alarm.
3. The Alarm Icon  will show when active.

Snooze: When alarm sounds, press the **SNOOZE** button to silence alarm for five minutes. The Snooze Icon  will flash.

Note: Press any button except SNOOZE to stop a sounding alarm or exit Snooze Mode. The alarm will remain active for the next day.

LOW BATTERY INDICATOR

- When the Low Battery Icon  appears, replace batteries.

WE’RE HERE TO HELP!

If you require additional support, get in touch with our friendly customer support team based out of La Crosse, WI.

Phone: 1-608-782-1610

Online: bit.ly/contact_techsupport

Our knowledgeable customer support team is available Monday-Friday, 8am-6pm CST.

STAY IN TOUCH

Ask questions, watch setup videos, and provide feedback on our social media outlets. Follow La Crosse Technology on Youtube, Facebook, Instagram, and X (Twitter).



SPECIFICATIONS

Temperature Range: +14°F to 122°F (-10°C to 50°C)

Power: 3 AA (LR6, IEC) batteries not included

Battery Life: Over 24 months

Dimensions: 16.75” L x 1.38” W x 10.75” H (42.54cm L x 3cm W x 27.3cm H)

CARE AND MAINTENANCE

Battery replacement instruction:

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery suitable for the intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment please check the internet or your local phone directory for local recycling centers and / or follow local government regulations.

WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

La Crosse Technology, Ltd, 2830 S. 26th St., La Crosse, WI 54601

For Full Warranty Details, Visit: www.lacrossetechnology.com/pages/warranty

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.


CAUTION!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.

 **WARNING:** This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: www.P65Warnings.ca.gov