

size: 203x162mm

front

LA CROSSE®
TECHNOLOGY

Model: BBB87276
Instruction Manual
DC: 031915

DIGITAL ATOMIC CLOCK

FRONT

Low Battery Alarm Icon Snooze Icon WWVB Icon Calendar

Radio-controlled Time Indoor Temperature

Foldout Stand Open

Battery compartment
3-“AA” batteries

GET STARTED

Step 1: Insert 3 new “AA” Alkaline batteries (not included) into the back of clock. Observe correct polarity.

Restart: Remove batteries from the clock, press a button 20 times. After 15 minutes, return to **Step 1** above.

SET TIME AND DATE

- Hold the **MODE** button to enter time set mode.
- Use the **+** or **-** buttons to adjust values. Press and hold for those buttons for fast adjustment.
- Press the **MODE** button to confirm adjustments and move to the next item.

Time and Date setting order:

- Beep On/OFF
- WWVB On/Off
- Time Zone
- Daylight Saving Time (DST) On/Off
- 12/24 Hour Time Format
- Hour
- Minutes
- Year
- Month
- Date
- Fahrenheit/Celsius

TIME ZONE	
AST	Atlantic
EST	Eastern
CST	Central
MST	Mountain
PST	Pacific
AKT	Alaska
HAT	Hawaiian

Note: Day of the week sets automatically when year, month and date are set. If day of the week is incorrect, check the year setting.

Press the **MODE** button to exit, or wait 20 seconds without pressing buttons to return to the normal time display.

SECONDS OR INDOOR TEMPERATURE DISPLAY

- Press the **MODE** button to select Seconds or Indoor Temperature to be displayed.

Seconds Display

Temperature Display

Model: BBB87276 www.lacrossetechnology.com/support Page | 1

Model: BBB87276 www.lacrossetechnology.com/support Page | 2

back

SET TIME ALARM

- Hold the **ALARM** button to enter alarm time set mode.
- Use the **+** or **-** buttons to adjust values.
- Press the **ALARM** button to confirm adjustments and move to the next item.

Alarm Time setting order:

- Hours
- Minutes

ACTIVATE / DEACTIVATE TIME ALARM

- Press the **ALARM** button once to view alarm time.
- Press the **ALARM** button again to activate the alarm. Bell icon appears.
- Press the **ALARM** button again to deactivate the alarm. The bell icon disappears.

SNOOZE (Silences alarm temporarily)

- Press the **SNOOZE** button to silence alarm for 10 minutes.
- Zz** will show next to the alarm bell.

Note: The alarm is crescendo sound. The alarm will sound for 2 minutes and then shut off completely.

WWVB MANUAL TIME SEARCH

Press the **+** button to start or stop a manual signal search. WWVB Icon will flash.

For information about WWVB visit:
www.nist.gov/pml/div688/grp40/wwvb.cfm

ATOMIC SIGNAL SEARCH:
After the initial search, this clock will only search for the atomic signal after midnight.

CARE AND MAINTENANCE

- Do not mix old and new batteries
- Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.

- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+and -).
- Remove batteries from equipment when is not to be used for an extended period of time.
- Remove used batteries promptly.
- Do not expose to extreme temperature, vibration or shock.
- Clean with a soft damp cloth. Do not use solvents or scouring agents.
- The product is not a toy. Keep it out of reach of children.
- The product is not to be used for medical purpose or for public information. It is intended for home use only.
- The specs of this product may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.
- If the product is not working properly, change the batteries.

SPECIFICATIONS

Indoor Temperature:	32°F to 122 °F (0°C to 50°C)
Batteries:	3-AA, IEC, LR6 batteries (not included)
Battery Life:	Battery life is over 12 months with reputable battery brands.
Dimensions:	15.42" x 7.33" x 1.14" (39.16cm x 18.62cm x 2.90cm)

WARRANTY AND SUPPORT

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

View full warranty details online at:
www.lacrossetechnology.com/warranty_info.pdf

Before returning a product, please contact our friendly customer support with questions or visit our online help (manuals and FAQs):

La Crosse Technology, Ltd
2830 South 26th St
La Crosse, WI 54601

Contact Support:
1-608-782-1610

Online Product Support:
www.lacrossetechnology.com/support

Product Registration:
www.lacrossetechnology.com/support/register

Model: BBB87276 www.lacrossetechnology.com/support Page | 3

Model: BBB87276 www.lacrossetechnology.com/support Page | 4