


## **Equity Wall Clocks**

**Operating Manual** 



Battery: Insert one new 'AA' Alkaline battery according to the polarity marks in the battery compartment.

Time Set: Turn the time set knob to the desired time.

This clock will be accurate to within a few minutes per year. Should the timekeeping suddenly fluctuate, replace the battery.

www.equitybylacrosse.com/support

## RATTERY INSTRUCTION

- 1. Always purchase the correct size and grade of battery most suitable for the intended use.
- 2. Clean the battery contacts and also those of the device prior to battery installation.
- 3. Ensure the batteries are installed correctly with regard to polarity (+and-).
- 4. Remove the batteries from equipment which is not to be used for an extended period of time.
- 5. Remove used batteries promptly.

## Two Year Warranty (U.S.A.)

Equity products are warranted for two years from the date of consumer purchase against defects in material and workmanship. During this period such defects will be repaired, or the products will be replaced at Equity's option. without charge. This warranty does not cover damage caused by misuse or negligence, ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABLITY ARE LIMITED IN DURATION TO A PERIOD ENDING TWO YEARS FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied will last so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your clock isn't working, send it with a letter explaining the problem and \$5.00 for

Equity by La Crosse Warranty Department 2830 26th St. S. La Crosse, WI 54601



Please help in preservation of the environment and return used batteries to an authorized depot. Remove the battery from the clock if you do not intend to use for an extended period of time



PRINTED IN CHINA