


**Alarm Clock Charging Station**  
with 2 USB Charging Ports




For online video support: <http://bit.ly/LaxTechTalk>

**Table of Contents**


Buttons .....	1
LCD Features .....	1
Setup .....	1
Settings: Language, time, Date, etc. ....	2
Nap Feature .....	3
Backlight (HI-LOW-OFF) .....	3
USB Charge Ports .....	4
Cable Hooks .....	4
Time Alarm .....	5
Activate/Deactivate Alarm .....	6
Snooze .....	6
Low Battery Icon .....	6
Care and Maintenance .....	6
Specifications .....	6
Warranty and Support .....	7
FCC Statement .....	7
Visit Us on Social Media .....	7

## **Buttons (on top)**




## **LCD Features**

- ① Time (manual set)
- ② Low Battery Icon
- ③ Alarm Icon (M-F)
- ④ Weekday, Nap duration, or Snooze duration
- ⑤ Month/Date
- ⑥ Indoor Temperature
- ⑦ Indoor Humidity
- ⑧ USB 1 Charge Indicator
- ⑨ USB 2 Charge Indicator
- ⑩ USB 1 Charge Port 1 Amp
- ⑪ USB 2 Charge Port 2 Amp



## **Setup**

1. Insert the 5.0 volt power cable into the outlet, then into the clock.
2. (Optional), Insert 2 AAA batteries (not included) into the clock.
3. Set language, time, calendar, temperature unit and snooze duration.



**Settings: Language, Time, Date, etc.**


- Hold the **SET** button to enter time set mode.
- Press the **+/-** buttons to adjust the values.
- Press the **SET** button to confirm adjustments and move to the next item.
- Press the **SNZ/LIGHT** button at any time to exit.

**Time set order:**

1. Language (English or Spanish)
2. Beep ON/OFF
3. Hour
4. Minutes
5. Year
6. Month
7. Date
8. Fahrenheit/Celsius
9. Snooze duration (5 minutes-120 minutes)

**Begin:** Hold the **SET** button for 3 seconds. ENGLISH will show.

**Language: English or Español**



When Español is selected, the instructions on screen will be in Spanish.

**BEEP ON | OFF**





**Hour | Minutes**



**Year | Month | Date**



**Fahrenheit | Celsius**



**Snooze Duration (5-120)**



## Nap Feature


Sometimes, we just want a quick nap without having to set a new alarm. Set the nap duration one time, then, a simple press of the **NAP** button starts the nap countdown.

### **Set Nap Duration:**


1. Hold the **NAP** button for 3 seconds. **NAP** and the duration will show (default is 10 minutes).
2. Use the **+/-** buttons to select a nap duration (up to 120 minutes).
3. Press the **NAP** button to confirm and start nap count down to zero.
4. Press the **SNZ/LIGHT** button at any time to exit.



**Set Nap duration**



**Active Nap Time Countdown**



### **Ready for a Nap?**

Press the **NAP** button once, and the clock will wake you.

- Press the **NAP** button once to start the nap feature. **NAP** will show with the preset duration.
- Minutes and seconds will countdown.
- When the alarm sounds **NAP** and **0m** will flash. The alarm will sound for two minutes and then stop if no buttons are pressed.
- Press any button except **SNZ/LIGHT**, at any time to exit nap mode.



## Backlight (HI-LOW-OFF)

- When operating with the power cable, the backlight is adjustable: HI-LOW-OFF.
- Press and release the **SNZ/LIGHT** button to adjust the backlight.
- When operating on batteries only, the backlight will come on briefly when the **SNZ/LIGHT** button is pressed.

## **USB Charge Ports**



**USB Output:** Up to 3 Amps total (both ports in use)

- Charge devices that self-regulate.
- Do not charge multiple devices from the same USB port.
- For tablets and other high power devices, use the USB port on the right (2 Amp).
- Must operate clock with power cable to charge other devices.
- Plug your device into one of the USB ports.
- The clock will show HELLO for 3 seconds.
- The lightning bolt will flash while charging.
- When no device is connected, no battery will show.
- As your device becomes full and less current is drawn, solid battery icon may show, before the charge is complete.



## **Cable Hooks**

- On the back of the clock there are two cable hooks to secure your charging cables.
- Simply slide your cable into the hook and the end of your cable will be easy to find every time.






# Time Alarm

- Press and release the **ALARM** button to view alarm time.
- With alarm time showing, hold the **ALARM** button for 3 seconds to enter alarm settings.
- Set the time then select alarm type:  
(Single alarm, Mon-Fri alarm, or Weekend alarm)
- Setting and activating the alarm are separate functions.







## Alarm Type (choose the type for each alarm):

- **Daily/Single**-Will alarm at the same time every day when active.
- **Mon-Fri**-Will only alarm Monday through Friday when active.
- **Weekend**- Will only alarm Saturday and Sunday when active.

Daily   Single	Mon-Fri	Weekend
		

## Set Alarm:

1. Press and release the **ALARM** button to view alarm time.
2. With alarm time showing, hold the **ALARM** button for 3 seconds to enter alarm time set mode.
3. Press the **+/-** buttons to adjust the alarm hour.
4. Press the **ALARM** button to confirm and move to the minutes.
5. Press the **+/-** buttons to adjust the alarm minutes.
6. Press the **ALARM** button to confirm and move to alarm type.
7. Use the **+/-** to select SINGLE, MON-FRI or WEEKEND alarm.
8. Press the **ALARM** button to confirm and exit.

Hour   Minutes		Alarm Type	
 6: ALARM	 :30 ALARM	 6:30 TYPE	
Single	Mon-Fri	Weekend	
 6:30 SINGLE	 6:30 MON-FRI	 6:30 WEEKEND	



## Activate/Deactivate Alarm

- When you finish settings, the alarm is active.
- From the normal time display, press and release the **ALARM** button to view alarm.
- Press and release the **ALARM** button to deactivate or to activate the alarm.
- When active the alarm clock icon will show.
- The clock icon will not show if the alarm is not active.



## Snooze

- When the alarm sounds, press the **SNZ/LIGHT** button. The alarm will be silent for the preselected snooze duration.
- SNOOZE - duration will show, and the snooze time will count down.
- When alarm sounds again, the **SNOOZE - 0** will flash.



Note: This is a crescendo alarm. It will sound for two minutes then shut off completely if no buttons are pressed.

## Low Battery Icon

- The low battery icon will appear between the hour and minutes.
- This icon indicates it is time to replace the batteries.

## Care and Maintenance

- Do not mix old and new batteries.
- Do not mix Alkaline, Standard, Lithium, or Rechargeable Batteries.
- Always purchase the correct size and grade of battery suitable for use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts prior to battery installation.
- Ensure the batteries are installed with correct polarity (+ and -).
- Remove batteries from equipment when it is not used for extended period.
- Promptly remove expired batteries.

## Specifications

**Temperature Range:** 32 °F to 122°F (0°C to 50°C)

**Humidity Range:** 10%RH to 99%RH

**Power:** 5.0V AC6: HX36-0503500AU

Optional-2-AAA, IEC, LR3 batteries (not included)

**USB Output:** 1 Amp and 2 Amp

**Battery Life:** Battery life is over 24 months with reputable batteries

**Dimensions:** 3.74" W x 2.40" D x 5.24" H (95 x 61 x 133 mm)

## **Warranty and Support**

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

**Before returning a product, please contact our friendly customer support with questions or visit our online help:**

**Phone:** 1-608-782-1610

**Online Product Support:**

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

**Product Registration:**

[www.lacrossetechnology.com/support/register](http://www.lacrossetechnology.com/support/register)

**View full warranty details online at:**

[www.lacrossetechnology.com/warranty\\_info.pdf](http://www.lacrossetechnology.com/warranty_info.pdf)

**Warranty Address:**

La Crosse Technology, Ltd

2830 S. 26th St.

La Crosse, WI 54601

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

**Operation is subject to the following two conditions:**

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### **Caution!**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.

## **Visit Us on Social Media**



For personalized interaction  
[http://bit.ly/LaxTech\\_Facebook](http://bit.ly/LaxTech_Facebook)



Latest video content  
[http://bit.ly/LaxTech\\_YouTube](http://bit.ly/LaxTech_YouTube)



Join the conversation  
[http://bit.ly/LaxTech\\_Twitter](http://bit.ly/LaxTech_Twitter)



Pin and share  
[http://bit.ly/LaxTech\\_Pinterest](http://bit.ly/LaxTech_Pinterest)