Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126
E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Counter Top Fabric Banner Display (Straight Across)

- 1. Connect side upright (long poles with one push button) to base. Repeat for opposite side (fig. A).
- 2. Connect top corner bracket to the side upright (long poles with one push button). Repeat for opposite side (fig. B).
- 3. Connect side section with bottom crossbar (poles with two push buttons) and center upright. Repeat for opposite side (fig. C).
- 4. Connect side section with top crossbar (short poles with one push button) and center upright. Repeat for opposite side (fig. D).
- 5. Slide pillowcase graphic over the frame and zipper it closed to complete assembly (not shown).

NOTE: Model shown below may differ from your model, but assembly instructions remain the same.





