Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126 E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Extra Large Lightweight Aluminum Display Easels

- 1. Adjust telescopic leg length (fig. A).
- 2. Open easel (fig. B).
- 3. (if using top bar) Open top bar and insert carriage bolts and wingnuts (fig. C).
- 4. Adjust lower canvas supports (fig. D).

