Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126 E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

FIRST RATE Aluminum Studio Easel

- 1. Rotate crossbars on back leg support so that notch is facing upwards (fig. A).
- Lay center upright face down. Attach back leg support by sliding carriage bolts into center upright channel and tightening (fig. B).
- 3. Lay side legs face down. Attach back leg support to side legs with wingnuts (fig. C).
- Stand up easel. Attach bottom canvas tray by sliding carriage bolt down side channel legs and tightening (fig. D).
- Attach metal feet to frame holder and utility tray (fig. E-1), then slide into support channel and tighten (fig. E-2).
- 6. Rotate palette holders if needed (fig. F).



