Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126
E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

GALLERY Aluminum Studio Easel

- 1. Attach base to main upright using carriage bolts and wingnuts (fig. A).
- 1. Open back leg support and secure with wingnut (fig. B).
- 4. Attach metal feet to frame holder and utility tray (fig. C-1), then slide into support channel and tighten (fig. C-2).
- 3. Rotate palette holders if needed (fig. D).









