
# Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126 E-MAIL: customerservice@accessdisplaygroup.com

## **Instruction Sheet**

## **Outdoor Enclosed Dry Erase**



### Step 1

Drill holes in sides of the case. Screw legs into the sides of the case. (make sure drain holes are on the bottom of the unit when drilling into case).

#### Step 2

Outdoor rated clear sealant can then be used to close up any holes to protect the display.

\*When displaying, it is recommended to bury leg posts 3 feet into the ground for stability.

Simple hand tools required: Level, Drill, Screwdriver