


Instruction Sheet

Outdoor Enclosed Menu Case With Legs



Step 1

Drill holes in sides of the case. Screw legs into the sides of the case. (make sure drain holes are on the bottom of the unit when drilling into case).

Step 2

Outdoor rated clear sealant can then be used to close up any holes to protect the display.

*When displaying, it is recommended to bury leg posts 3 feet into the ground for stability.

Simple hand tools required: Level, Drill, Screwdriver