

Swinging Banner Sign Floorstand

1. Attach graphic curved rod to telescopic pole. Pole clutch lock remains tightened (fig. A).
2. Insert pole into base sleeve and tighten knob (Fig. B).
3. Hang up banner on hooks.
4. Loosen clutch lock 1/4 to 1/2 turn in order to position banners to desired height then tighten clutch lock (Fig. C).

