


POP UP PORTABLE DARK DEN INSTRUCTIONS

SETTING UP YOUR DARK DEN:












COLLAPSING YOUR DARK DEN:


TENT CONTENTS:














Do not leave children unattended. Adult assembly only.

Ensure that the area is free from sharp objects and stones to prevent puncture or tearing in base. Always check for damage every time before use.

Do not use this product if one of the elements is broken, torn or missing.

Store in cool dry place when not in use.

Store in a place out of reach of children.

Do not force the frames or they will be damaged.

Not suitable for persons under 36 months, contains small parts. Choking hazard.

Keep the information for future reference.

Made in China

