FLEX-Elektrowerkzeuge GmbH Bahnhofstraße 15 71711 Steinheim Phone +49 7144 828-0 Fax +49 7144 25899 info@flex-tools.com www.flex-tools.com

2-speed cordless mixer with 3-level speed switch 18.0 V

MXE 18.0-EC/5.0 Set + WR2 120

Order number 495.972



2-speed cordless mixer with 3-level speed switch 18.0 V

+ Electronic management system (EMS) protects the machine, extends the service life, and increases efficiency

+ Brushless motor with greater efficiency and a longer service life

+ Large, rugged 2-gear unit with optimum ratios for powerful torque and correct speed for different materials

+ Comfortable 3-level switch can be reached from the grip position without interrupting work, protected by a rubber sleeve. Level 1: cleaning, level 2: stirring up, level 3: mixing

+ Rotary switch to set the optimum mixing speed. Speed 1: for highly viscous materials, speed 2: for medium and low viscosity materials

+ Accelerator switch for a slow and gentle start

+ On/off switch with lock and protection

+ The flexible rubber sleeve over the on/off switch prevents the ingress of dirt. No malfunctions caused by jammed switches

+ Ergonomic handles on the drive unit: low weight, fatigue-free arm posture and upright body posture allow comfortable, ergonomic operation

+ Four corner guards with rubber buffer provide secure storage during transportation and offer protection against shocks and impacts at the building site

+ Protective cap above the motor housing guides the cooling air flow and prevents the ingress of splashing water

+ Patented spindle lock with start-up protection. For tool-less exchange of the mixing paddle + For mixed applications up to 30 kg

+ With mixing paddle WR2 for mixture: pasty to tough. Tile adhesive, grout, filler compound, adhesive, finished plaster, adhesive mortar, ...

+ FLEX battery system: suitable for all FLEX 18,0 V battery packs