

# Operation

\* Insert the adaptor into the socket located at the rear of the winder and plug the other end into your electrical outlet.

OFF: : Turn off



: Clockwise (1000 TPD)



: Counter-clockwise (1000 TPD)



: Alternating (1000 TPD)



: Alternating (1500 TPD)



- TPD: Turns Per Day. Working 12 hours a day, stopping for 12
  - Clockwise: Rotates clockwise for 2 minute, rests for 6 minutes and then repeats.
  - Counter-clockwise: Rotates counter-clockwise for 2 minute, rests for 6 minutes and then repeats.
  - Alternating 1000 TPD: Rotates clockwise for 2 minutes, rests for 6 minute, rotates counter-clockwise for 2 minutes, rests for 6 minutes and then repeats.
  - Alternating 1500 TPD: Rotates clockwise for 5 minutes, rests for 6 minute, rotates counter-clockwise for 5 minutes, rests for 6 minutes and then repeats.
- \* *Most watches on the market only require clockwise winding. However, some brands may require alternating rotation. Please consult with your watch manufacturer for more information.*

## NOTE

- Please only use the AC adaptor provided.
- Remove the adaptor when the winder is not in use.
- Always turn off the power when inserting or removing watches.
- Do not shake or rotate when the winder is stationary.
- When inserting and removing your watch, please ensure the electrical supply is turned off as it may cause the winder to malfunction.
- Please dispose of this product responsibly at an approved disposal site or recycling facility. Do not dispose of this item in normal household waste.



**HAMILTON**  
**WATCH WINDERS**

**ZOE SINGLE WATCH WINDER  
INSTRUCTION MANUAL**

**CONTACT US:  
HAMILTON WATCH WINDERS**

4 BLENHEIM COURT  
INGLEBY BARWICK  
STOCKTON ON TEES  
TS17 5HU

TEL: 01642 049072

WEB: [WWW.HAMILTONWATCHWINDERS.CO.UK](http://WWW.HAMILTONWATCHWINDERS.CO.UK)

EMAIL: [ACCOUNTS@HAMILTONWATCHWINDERS.CO.UK](mailto:ACCOUNTS@HAMILTONWATCHWINDERS.CO.UK)