




Clothing Stamp Ink Replacement Pad Instructions



1. On the back of the stamp, slide the lock button to the unlock position.
2. Remove the clear plastic cover from your replacement ink pad and set it aside.
3. Gently push up on the clear plastic portion of the stamp. This will raise up the opening of where you will insert your replacement ink pad.
4. Holding onto the finger grips on the replacement ink pad, insert it into the opening of your stamp; ink side up.



Call Everything Summer Camp at 1-800-535-2057 if you have any questions.