

Handle Replacement Instructions (#53, 56)

What's Included: Handle, 5 screws (extras included)

Tools Needed: Phillips head screwdriver



- 1. Remove the five screws from the Handle piece. Disgard the old screws and use the new screws provided with the replacement handle.
- 2. Place the new Handle piece in place and screw back on your trunk in its original position.

If the existing screw holes in the trunk seem too loose, you can move the handle down slightly and create new holes.

