




Hinge (Pre 2019) Replacement Instructions (#54, 55)

What's Included:
Hinge, 6 screws (extras included),
security screw bit

Tools Needed:
Phillips head screwdriver or
cordless drill with phillips head bit



1. Using the included drill bit, remove the six security screws from the Hinge piece. (Figure 1)
2. Place the new Hinge piece in place and screw it back on your trunk in its original position using the six replacement screws provided. Discard the old hinge and screws.



SECURITY SCREW



PHILLIPS HEAD SCREW