

Quick instructions for the Superior Airco 5000 Air conditioner remote control.

The remote control has already programmed with the leading brands remote codes so first thing is to insert the batteries and try the remote control on you're a/c unit. If it works then you're ready. If not, proceed to the below:

Step 1. Automatic search

Point the remote control to the A/Conditioner unit and press the Power button. Press "SET" and keep on pressing until "----" appears on the remote control and your air conditioner has switched on. Try the other buttons of the remote control and in case any of them don't work, repeat the above procedure.

Step 2.

In the unlikely event the above don't work, you would need to manually set-up the remote. Have a look at the accompanying leaflet and find your a/conditioner brand.

Press the "set" and "on/off" button until the code begins flashing. Use the buttons "Temp up" and "Temp down" to reach the 4 digit code you found above. Once you found the code, press "SET" to save. The remote should now be set so just try it on your air-conditioner now. If it does not, try the next code on the list.