

Cheerble

USER MANUAL

Wicked Mouse **Neo**

EN

BEFORE USE


Thank you for choosing Cheerble Wicked Mouse Neo.

To ensure safety and the proper use of the product, please read the user manual and accompanying materials carefully before installing or using the product. Our company is not liable for any personal injury, property damage, or other losses caused by improper use.

CAUTIONS

1. Check the product for damage before each use and do not use it if damaged to avoid injury. If any abnormalities occur during use, stop using the product immediately.
2. Supervise your pet when playing with the product to avoid accidental ingestion.

PRODUCT OVERVIEW



Gently pull the wheels out to remove hair. To reattach, align the wheels with the slots and press until they click.

OPERATION INSTRUCTIONS

Power on and switch interactive modes.

On / Off

Press and hold for 3 s

Switch Modes

Short press

*A short “beep” sound indicates mode switching, and the product will automatically enter the selected mode if no button is pressed within 5 s.



Solid Blue: Normal Mode




Solid Green: Gentle Mode

OPERATION INSTRUCTIONS



1. To avoid accidental mode changes, switching modes is disabled during use. To switch modes again, restart the product first.
2. The product will reactivate if tapped while still.
3. To ensure a healthy balance between play and rest for your pet, the product will sleep for 30 minutes after each 10-minute activity. During this sleep period, you can wake it up by tapping, or it will automatically reactivate after 30 minutes.




Colorful: Moving



Flashing Yellow: Still or Sleeping



CHARGING

-  Flashing Red: Low Battery
-  Flashing Yellow: Charging
-  Solid Green: Fully Charged




1. Always keep the charging port clean and dry.
2. Please charge the product if any of the following occurs:
 - (1) After powering on, the indicator light flashes red and the product shuts down.
 - (2) The product emits regular long “beep” sounds with the indicator light flashing red.
 - (3) The product does not power on after long pressing the function button.

BEEP ALERTS



Status	Meaning	Actions Required
Regular long “beep” sounds with the indicator light flashing red	Low battery	Charge the product or power it off
Regular long “beep” sounds with the indicator light flashing yellow	Movement blocked for over 2 min	Tap the product to reactivate it, power it off, or wait 30 min for auto-reactivation
A short “beep” sound when short pressing the function button	Mode switching	/

SPECIFICATIONS



Model:	CWJ03
Main Materials:	ABS, PVC, Synthetic Fiber
Dimensions:	2.6 × 2.1 × 1.5 in / 65 × 54 × 39 mm (excluding the rope tail)
Weight:	2.1 oz / 60 g
Battery:	200 mAh
Input:	5V $\overline{\text{---}}$ 1A
Operating Temperature:	41°F to 104°F / 5°C to 40°C

LIABILITY TERMS

Advice for Use

Apart from playing with this product, it is recommended that you interact with your pet and provide a variety of play activities. Opportunities for stimulation or the appropriate amount of daily exercise should be determined by veterinarian.

Warranty

One-Year Limited Warranty

Cheerble warrants the included hardware product and accessories against defects in materials and workmanship for one year from the date of original retail purchase. Cheerble does not warrant against normal wear and tear nor damage caused by accident or abuse. Complete details of the warranty applicable to this product and its terms can be found at www.cheerble.com.

Terms of Use and Limitation of Liability

1. Terms of Use

The use of this product is subject to your acceptance without modification of terms, conditions and notices contained with this product. Use of this product implies acceptance of all such terms, conditions, and notices. If you do not wish to accept these terms, conditions, and notices, please return the product, unused, in its original packaging and at your own cost and risk with proof of purchase for refund.

LIABILITY TERMS

2. Proper Use

Proper use includes, without limitation, reviewing the entire user manual and any specific safety information statements. The specific temperament or size/weight of your pet may not be suitable for this product. If you are unsure whether this product is appropriate for your pet, please consult your veterinarian to use.

3. No Unlawful or Prohibited Use

This product is designed for use with pets only. This product is not intended to harm, injure or provoke. Using this product in a way that is not intended could result in violation of local laws.

4. Limitation of Liability

In no event shall Shenzhen Cheerble Technology Co., Ltd. or any of its associated companies be liable for (i) any direct, indirect, punitive, incidental, special or consequential damage and/or (ii) any loss or damages whatsoever arising out of or connected with the use or misuse of this product.

5. Modification of Terms and Conditions

Shenzhen Cheerble Technology Co., Ltd. reserves the right to change the terms, conditions and notices governing this product from time to time. If such changes have been notified to you prior to your use of this product, they shall be binding on you as if incorporated herein.

FCC COMPLIANCE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer, or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by Shenzhen Cheerble Technology Co., Ltd. could void the user's authority to operate the equipment.

Cheerble

Manufacturer: Shenzhen Cheerble Technology Co., Ltd.
Address: 2801, West Tower, Lepu Building, 66 Xingke Road,
Xili Subdistrict, Nanshan District, Shenzhen, China



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

