

Boppy® Shopping Cart and High Chair Cover



Boppy® Shopping Cart and High Chair Cover

Recommended age: 6 - 48 months

- Ensure baby can sit up unassisted before product use.
- Drape cover over the cart's seat.
- Weaving the belt around the back of cart's seat.
- Secure with the elastic corners.
- Securely fasten the buckle around the child.

Washing Instructions:

- Machine wash with mild detergent, delicate cycle 30°C (65° - 85°F). Do not bleach.
- Drip dry, hanging in shade. Do not squeeze. Do not iron. Do not dry clean.
- Toys: spot clean only. Air dry.

WARNING

TO PREVENT SERIOUS INJURY OR DEATH

- NEVER leave child unattended with this product at any time.
- Adult supervision is required at all times when product is in use.
- Improper use of this product could result in serious injury or death.

FALL HAZARD

- ONLY use product with a child who can sit upright unassisted.
- ALWAYS secure belt to shopping cart by looping the belt through the back grid of the shopping cart seat before buckling child.
- DO NOT use on a shopping cart that is not designed for seating a child.
- When using this product with a high chair, be sure to secure the child with the child restraint straps in the high chair.
- DO NOT use if the child restraint straps are missing or damaged.

ENTRAPMENT HAZARD

- NOT A TOY - When product is not being used, be sure to leave restraint unbuckled to prevent possible entrapment.

PINCH HAZARD

- Carefully buckle child in to avoid pinching.

ADVERTENCIA

PARA EVITAR UNA LESIÓN GRAVE O LA MUERTE

- NUNCA dejar al niño sin supervisión con este producto en ningún momento.
- Se requiere la supervisión de un adulto en todo momento cuando esté en uso el producto.
- El uso indebido de este producto podría provocar lesiones graves o la muerte.

PELIGRO DE CAÍDA

- SOLO usar el producto con un niño que pueda sentarse derecho sin ayuda.
- SIEMPRE sujetar el cinturón al carrito de compras pasando el cinturón por la rejilla posterior del asiento del carrito de compras antes de abrochar al niño.
- NO usar en un carrito de compras que no esté diseñado para sentar a un niño.
- Al usar este producto con una silla alta, fijarse en asegurar al niño con las correas de sujeción que tiene la silla alta.
- NO usar si faltan las correas de sujeción o se ven dañadas.

PELIGRO DE ATRAPAMIENTO

- NO ES UN JUGUETE - Cuando no esté en uso el producto, revisar que la correa de restricción se deje sin abrochar para evitar que el niño quede posiblemente atrapado.

PELIGRO DE COMPRESIÓN

- Abrochar al niño con cuidado para evitar pellizcos.