Boppy® Tummy Time Prop



Boppy® Tummy Time Prop

- Only use this product on the floor with adult supervision.
- Position baby so underarms are supported.
- Check with your pediatrician to ensure baby is ready for these milestones.

Washing Instructions:

- Machine wash prop, delicate cycle, 30°C/85°F.
 Non-chlorine bleach as needed.
- Tumble dry low on delicate cycle. While drying, throw a sneaker or tennis ball (wrapped in a pillowcase) in the dryer to help the prop keep its shape.
- Do not iron. Do not dry clean.
- Remove toys: spot clean only. Air dry.
 Do not remove plastic ring.

WARNING

TO PREVENT SERIOUS INJURY OR DEATH

- · Adult assembly required.
- ONLY use under adult supervision.
- . NEVER leave child unattended.
- DO NOT use in crib, cradle, bassinet, playpen, play yard or bed.
- ONLY use this product on the floor.

SUFFOCATION HAZARD

- . NEVER allow baby to sleep on the product.
- ENTANGLEMENT OR STRANGULATION HAZARD
- DO NOT add strings or straps to product.

CHOKING HAZARD

 ALWAYS inspect product and toys before each use. Make sure all of the parts are securely attached. If any part is frayed or loose, discontinue use and throw the part away.

AADVERTENCIA

PARA EVITAR UNA LESIÓN GRAVE O LA MUERTE

Lo debe armar un adulto.

SLEEP

- SOLO usar bajo la supervisión de un adulto.
- · NUNCA dejar al niño sin supervisión.
- NO se debe usar en la cuna, moisés, corral de juego, patio de juego ni en la cama.
 SOLO debe usarse este producto sobre el suelo.

DORMIR

PELIGRO DE SOFOCACIÓN

- NUNCA dejar que el bebé duerma sobre el producto.
- PELIGRO DE ENREDO O ESTRANGULACIÓN
- NO agregar cuerdas ni correas al producto.

PELIGRO DE ASFIXIA

 SIEMPRE inspeccionar el producto y los juguetes antes de cada uso. Revisar que todas las piezas estén instaladas firmemente. Si hay alguna pieza deshilachada o suelta, se debe dejar de usar y descartarla.