

### READ ALL PRECAUTIONS AND INSTRUCTIONS IN THIS MANUAL BEFORE USING THIS EQUPIMENT.

KEEP MANUAL IN A SAFE PLACE FOR FUTURE

TOTAL WEIGHT CAPACITY = 300KG

AGE OF USERS 3+ SAFETY STDS EN71, ATSM 1188, EN1176

ABN: 36 627 796 141

P.O Box 2527, Clarkson, WA, 6030

Model: CP20 – REV 3

# **BEFORE YOU BEGIN**

Thank you for purchasing Growplay Monkey Bars. With regular maintenance, your set will provide many years of backyard fun.

Before you start to assemble your new GROWPLAY MONKEY BAR SET please ensure that you have read this important information and that it is communicated to all users prior to use.

## **INSTALLATION WARNING!**

### WARNING: THIS DISASSEMBLED PRODUCT MAY CONTIAN SMALL PARTS WHICH POSE A CHOKING HAZARD TO CHILDREN UNDER 3.

- Read all important precautions and instructions in this manual and all warnings on the equipment to reduce the risk of serious injury.
- It is the responsibility of the owners and supervisors of this equipment to ensure that it has been correctly assembled, anchored, maintained and the users obey the safety instructions.
- This product is intended for use by children AGE OF USERS 3+
- Until the equipment has been correctly assembled and anchored, do not let children use equipment.
- Always use Growplay Monkey Bars under adult supervision.
- It is required that the play equipment be ground anchored with the ground anchor nails provided onto a soft or shock absorbing surface.
- Do not install over concrete or any other hard surface as a fall onto a hard surface could result in serious injury or death.
- Ensure that the equipment is installed on a level surface and no less than 1.8 metres from any structure or obstruction.
- Always inspect the equipment before it is used and replace any worn, defective, or missing parts.
- Ensure that all connectors are regularly checked.

### WARNING: ACCESSORIES MUST ONLY BE ATTACHED IN POSITIONS AS SHOWN IN THESE INSTRUCTIONS. FAILURE MAY RESULT IN DEATH OR SERIOUS INJURY.

# **ELECTROCUTION HAZARD**

Growplay monkey bars are made from metal. They are not grounded and will conduct electricity. For obvious reasons and electrocution hazard exists. NO lights, heaters, electrical and extension cords or any household electrical device or appliances are to be permitted on or in the frame at any time.

### FOR THE USER

- Do not use this equipment when under the influence of drugs or alcohol.
- Do not jump on or off the frame.
- Wear clothing that does not have loops, hooks, drawstrings, or anything else that can get caught on the frame.

# **USER INSTRUCTIONS**


- 1. GROWPLAY MONKEY BARS are designed for up to 6 persons and not exceeding total weight of 300kg.
- 2. AGE OF USERS 3+
- 3. Adult supervision for children of all ages is required at all times.
- 4. Educate children not let to walk close to, behind and in front, between moving parts.
- 5. Children are not to use the equipment in any other manner than intended.
- 6. Teach children not to hop off equipment while in motion or jump from moving play items.
- 7. Do not twist chains or ropes or loop them over support bars as this may reduce the structural integrity of the rope or chain.
- 8. Do not allow use of the equipment when it is wet as injury due to slips may occur.
- 9. Children are to be dressed in appropriate clothing while playing on or around the equipment with correctly fitted and full foot enclosing footwear. Loose fitting items, hood, and neck draw strings etc could potentially cause injury or death by strangulation.
- 10. Inform children not to attach items to the playground equipment that are not specifically designed or approved for use with the Growplay monkey bar equipment, such as, but not limited to jump ropes, clothesline, pet leashes, cables, and chain as they may cause a strangulation hazard.


### **ASSEMBLY: TWO PERSONS**




Before starting assembly, please carefully read the following information.


- Two people are required to assemble frame.
- DO NOT FULLY TIGHTEN BOLTS UNTIL FRAME IS ASSEMBLED.
- Place all parts in one cleared area and remove the packaging material. Do not throw away material until assembly is complete.
- Dispose of the packaging thoughtfully and ensure any plastic bags and small parts are kept away from children or pets.
- Ensure that you check all tightening of parts **twice** and that the frame is stable after assembly. Small movement through the frame is normal.
- Allow plenty of time to ensure that your monkey bars are set up correctly and safe to use.
- Ensure that no exposed red tape is present and that all fixtures are extremely tight.







### IMPORTANT! ONLY FULLY TIGHTEN BOLTS ONCE FRAME IS ASSEMBLED. FINGER TIGHTEN ONLY DURING ASSEMBLY.







ŋ












# FRONT SUPPORT BAR: IMPORTANT! LAY PARTS OUT AS SHOWN.


SLIDE ON SWING CLAMPS AND HAND TIGHTEN CHICAGO BOLTS. NOTE CLAMP SCREWS BOTH FACING INWARDS!!


NOTE CLAMP BOLTS FACING INWARDS. LOCATE SAFETY BOLT HOLE AND TIGHTEN INTO TUBE


















### GROUND ANCHORS <u>ONLY</u> REQUIRED FOR SOFT SAND CONDITIONS. THEY MAY BREAK WHEN INSTALLING INTO HARD GROUND.





# FINAL STEP. START AT ONE CORNER OF THE FRAME AND DOUBLE CHECK ALL BOLTS ARE TIGHT. SMALL MOVEMENT IN FRAME IS NORMAL. CONGRATULATIONS!

YOU HAVE ASSEMBLED YOUR GROWPLAY COMPACT MONKEY BAR!

### MAINTENANCE INFORMATION

This product was manufactured using quality materials and crafted to provide you and your family with many years of enjoyment and exercise. Proper maintenance care will help to prolong the life and reduce the possibility of injury. The following guidelines should be followed.

- Tighten all hardware at the beginning of each play season.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seats, ropes, cables and chains for wear, rust, or other deterioration. Replace as needed.
- Check metal parts for rust. If found, sand and repaint using a nonlead-based paint.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
- Twice a month during play season: Tighten all hardware, check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing. Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
- Once a month during play season: Lubricate all metallic moving parts per manufacturer's instructions. Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.
- At the end of each play season or if the temperature drops below 2 Deg C, remove plastic swing seats and other items as specified by the manufacturer and take indoors or do not use. Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary. Owners shall be responsible for maintaining the legibility of the warning labels.
- Disposal Instructions There shall be instructions advising the owner to disassemble and dispose of the playground equipment in such a way that no unreasonable hazards will exist at the time the playground equipment is discarded. If any these conditions exist, this product should be disassembled or otherwise protected from being used until the condition is fixed.



growplaymonkeybars.com