

pTron



## Bassbuds True Wireless Stereo Earbuds

Instruction Manual

### Button Operations:



**Note:** Please always carry the Charging case along with the earbuds

1

### Video Link:

<https://youtu.be/it8aooRkH2A>

### Video QR Code:

Scan to watch the product demo and troubleshooting



**Power ON:** Short Press MFB for 3 seconds on both the earbuds to Power ON. Blue & red LED will flash alternatively to indicate that earbuds are turned on.

**Power OFF:** Long Press MFB for 5 seconds on each earbuds to Power OFF both the earbuds.

2

### Google Assistance/Voice Assistant:

Short Press the MFB of either arbuds for 2 seconds to activate Google assistant/voice assisatnt function. The sound of two beep is to indicate that the function is active.

Receive/Hangup Call: Click MFB of either earbuds once.

**Call Reject :** Clitck MFB of either earbuds twice.

**Play/Pause:** Click MFB of either earbuds once.

**Next Song:** Click MFB of either earbuds twice.

**Previous Song:** Click MFB of either earbuds thrice.

### Wireless Connection:

1. Turn ON both the earbuds, blue & red light will flash alternatively to indicate that earbuds are turned ON.
2. Left & Right earbuds will get automatically paired to each other within seconds after getting turned ON.

3

3. Blue & Red light will flash alternatively to find the Bluetooth connection.
4. Turn ON the Bluetooth of Your device & search "PTron Bassbuds" in your Bluetooth device list to connect the earbuds.
5. Blue light will flash every 5 seconds after successful connection with the Phone.

### Charging:

1. The earbuds will power off automatically when placed into the charging box. In the meantime, the Red indicator is permanly ON during charging, and once it is full charged the Blue indicator will turn ON & after 15 seconds it will turn OFF.

2. After connecting the charging box with a micro USB, the charging indicator flickers blue light. If the first indicator flickers, the battery capacity of the charging box is around 25%. If the second indicator flickers, the battery capacity is around 50%. If the third indicator flickers, the battery capacity is around 75%.

4

And if the fourth indicator flickers, the battery capacity is 100%. The four indicators are permanently on with blue light after the case is fully charged.

3. The charging box is ON with blue light when the earbuds are getting charged, and the indicator is turn off after charging is finished. The number of blue indicators represents the battery capacity of the charging box.

**Note:** In case of low battery please charge the earbuds immediately to avoid connectivity issues.

### Specifications:

Bluetooth Version: v5.0  
Transmission Range: 10 Meters, Class II  
Bluetooth Profiles: A2DP/HFP/HSP/AVRCP  
Frequency Response: 18Hz-20KHz  
Driver Size:  $\Phi$  10mm  
Speaker Sensitivity: 105dB $\pm$ 3dB  
Mic Sensitivity: -42dB $\pm$ 3dB  
Speaker Impedance: 32 $\Omega$

5

Battery Capacity earbuds: 50mAh\*2, Li-Polymer  
Battery Capacity Charging Case: 400mAh, Li-Polymer  
Charging Input: DC 5V  
Charging Type: With Charging case  
Charging Time: About 1.5 Hours  
Music Play Time: About 6 Hours  
Talk Time: About 5 Hours  
Standby Time: About 100 Hours  
Product Weight: 22gm  
Operating Temperature: 0°C~50°C

### Disclaimer:

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.

6