



Fusion Pro BT Speaker - User Guide




Important: pTron 'Fusion Pro' Bluetooth speaker is set at default volume. You can increase or decrease the volume using the speaker knob or through the connected device

Getting Started & Charging:

- i. Unbox the Speaker and remove all packaging materials.
- ii. Place the speaker on a flat surface.
- iii. Connect the USB type C cable to the charging port on the speaker's back side, and connect the USB end of the Charging cable to a Power Source such as a USB Charger or other Charging Devices with a 5 volt(DC) output.
- iv. Charge the speaker fully before initial use for the best battery performance.

Bluetooth Pairing:

- i. Turn on the speaker by rotating the power knob to the right
- ii. The speaker will enter pairing mode automatically.
- iii. On your smartphone or tablet, enable Bluetooth and search for nearby devices.
- iv. When you see "pTron BT SPEAKER" in the list of available devices, select it to pair.
- v. Once the speaker is connected with the BT device it will respond with a voice prompt, "Ptron Bluetooth Speaker is Connected".



Basic Operation:

- I. **Power Knob:** Turn the power knob to the right to power on the speaker, and rotate it in the opposite direction to power it off
- II. **Volume control:** Adjust the power knob from right to left to control the volume, increasing or decreasing.
- III. **Play/Pause:** Single press the "pause/play" button to play or pause audio playback. Long press the "pause/play" button for disconnecting.
- IV. **Next/Previous track:** Single press the "Next" button to move to the next track, and Single press the "Previous" button to move to the previous track when playing Music.
- V. **Mode Button :** Long press "Next" button to change to the Speaker mode (Bluetooth, FM mode, USB Mode & TF Card Mode). Long press the "previous" button for TWS Mode.
- VI. **Call Answer/Hangup:** Single press "pause/play" button for call answer and Hangup.
- VII. **Call Rejected:** Double press "pause/play" button for call reject.
- VIII. **Re-Dial:** Double press "pause/play" button to re-dial.

Note:

- I. The speaker will automatically detect the TF card and USB drive after inserting these devices.
- II. The charging cable works as an FM antenna in FM mode, so it is mandatory to connect the charging cable in FM mode.

TWS function:

- I. Turn on both speakers and long press the "Previous" button for 2 seconds on each speaker to enable TWS mode. Both speakers will respond with a voice prompt saying "TWS mode".
- II. Place both speakers within close proximity. The speakers will automatically connect to each other.
- III. Now enable Bluetooth on your device and search for nearby devices.
- IV. When you see "pTron BT SPEAKER" in the list of available devices, select it to pair. Now you can enjoy music with both speakers.
- V. If you do not want to use TWS mode, long press the "previous" button for 2 seconds again.

FM Operation Process:

- I. Long press the "**Next**" button to switch to FM mode. Then, connect the charging cable to the charging port.
- II. After connecting the charging cable to charging port, then single press the **play/pause** button to scan the channels.
- III. The speaker will begin scanning, and the available channels will start playing one by one.
- IV. To listen to a channel, press the **play/pause** button once when your favorite channel plays.
- V. Then by single pressing the "**Next**" and "**Previous**" buttons, you can change the FM channels.

Troubleshooting:

- i. If the speaker do not pair with your Bluetooth device, make sure the speaker is in pairing mode and try again.
- ii. Check the volume level on both your audio source and the speakers to ensure they are not set too low.

Important: Please use this speaker within a 10 metre wireless range from the connected device

Safety Precautions

- Please keep this device away from extreme heat, liquids, humidity or corrosive environment.
- Please don't over-charge the product as it will decrease the service life of battery.
- Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty. We strongly recommend using a good quality DC5V-1A chargers & the USB cable included in the package.
- This product or the Bluetooth function should not be used during charging.
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect your hearing.
- Please don't open/temper the product or product's battery.
- Please keep the product out of children's reach.
- Dispose the product responsibly and adhere to your local authority guidelines.

What is Covered in Warranty?

- ✓ Manufacturing defects in materials and workmanship of the product ONLY. This warranty applies when the product is used under normal conditions and the purpose for which the product was designed.
- ✓ No warranty on product accessories..
- ✓ To avail warranty, Product Registration is Mandatory at <https://ptron.in/apps/product-registration>
- ✓ Please read through the complete warranty details at <https://ptron.in/pages/repair-service-warranty>

Customer Care Details:

Mail: support@ptron.in

Tel: 040 - 67138888

Service Centers List: <https://ptron.in/pages/ptron-service-centers>

Disclaimer: The colour and specifications shown in or mentioned in the user manual may differ from the actual product. Images shown are for representation purposes only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.