



Studio Pixel Wireless Headphones - Product Manual



Important: pTron Studio Pixel is set at 60% default volume. Please adjust the volume through this Headset or connected device.

Button Description:



'M' Mode Button

'o' Power On/Off Button

Power On & Pairing

1. Long Press Power button until Multiple LED light blinks alternatively to Enter Pairing mode.
2. Open Bluetooth function on your Device and Search for the Available Bluetooth devices.
3. Click on 'pTron BT' to connect.

Note: Button with a circle is Power On/Off button.

Power Off

Press Power button until LED multiple lights blink & Turn Off.

Bluetooth Connectivity - Automatic

Just Turn On the Wireless Headset. It will Automatically Connect to the Last Connected Device.

Note: The last connected smart device must be On, Bluetooth function must be On and must be within 10 meters wireless range from this Headset.

Instant Voice Assistant Activation

Triple click Power button to Awake your Phone's Voice Assistant.

Modes, Aux Port & Multiple Lights

1. **Music & Gaming mode** - Single Press Mode button 'M' to change the modes.
2. **Aux Port** - Plug the Aux cable with the Headset & connect it with your device. After aux connection Headset will automatically turn off in 3 sec and now you can enjoy music and call in power off mode.
3. **Multiple RGB Light** - Long press Mode button 'M' to turn off/turn on the multiple LED lights of the Headset.

Note:

1. Button with the letter 'M' is Mode button.
2. Aux (audio + mic) will work fine with Computers with a single port for mic & audio. If the Computer has separate ports mic & audio port then only audio will work.

Call & Music Functions

Answer/Hangup a Phone Call: Press Power button once.

Reject a Phone Call: Long Press Power button for 2 seconds.

Music Play/Pause: Press Power button once.

Next Song: Long Press "+" button.

Previous Song: Long Press "-" button.

Volume Up: Single Press "+" button.

Volume Down: Single Press "-" button.

Re-dial: Press Power button Twice in Standby mode.

Note: Button with a circle is Power On/Off button.

Charging the Headset

1. Turn Off the Headset before Charging.
2. Connect the Type-C End of the Charging cable to the charging port given in the Headset.
3. Connect the USB end of the Charging cable to a Power Source such as USB Charger or other Charging Devices of 5V Output.
4. Red LED light will be Steady during Charge. Once the Headset is Fully Charged, Red LED indicator will Turn Off.
5. Un-plug the Headset from the Charging cable.

Troubleshooting Scenario 1: Connectivity Issue

1. Turn OFF the Headset and charge 100%.
2. Unpair with the connected Bluetooth device.
3. Restart the Bluetooth device.
4. After 100% charging switch ON the Headset and pair it with the Bluetooth device again.

Troubleshooting Scenario 2: Headset Disconnecting During a Phone Call

1. Headset must be 100% charged before using (low battery can also cause call drops).
2. Unpair the Headset with your connected device and restart the device.
3. Pair the Headset again.

Note: This Headset has up to 10 meters of wireless transmission range in an open space. Going beyond the wireless range may cause disconnection.

Troubleshooting Scenario 3: Mic Not Working Properly

1. Unpair the Headset from connected device and restart the Bluetooth device.
2. Switch ON the Headset and pair it again with the Bluetooth device.
3. Please check for network for mic issue, when network is low mic performance goes down.
4. The distance between the Headset and the connected device must be within 10 meters.
5. Allow the mobile setting to use headset's mic.
6. Keep the boom mic towards your mouth direction.

Safety Precautions

1. Please keep this device away from extreme heat, liquids, humidity or corrosive environment.
2. Please don't over-charge the product as it will decrease the service life of battery.
3. Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty. We strongly recommend using a good quality DC5V-1A chargers & the USB cable included in the package.
4. This product or the Bluetooth function should not be used during charging.
5. Don't jam the ports such as charger port, LED port, etc.
6. It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the product service life.
7. Please don't open/temper the product or product's battery.
8. Please keep the product out of children's reach.
9. Dispose the product responsibly and adhere to your local authority guidelines.

Disclaimer

The colors and specifications shown or mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or on trade names of their respective owners.