

Tangent Pixel Wireless Neckband



Instruction Manual



Power On & Pairing

 Power On the neckband by Pressing the MFB until Blue & Red LED light blinks alternatively.
Long Press MFB until Blue & Red LED light blinks alternatively to Enter Pairing mode.
Open Bluetooth function on your Device and Search for the Available Bluetooth devices.
Click on 'pTron BT' to connect.

Note: MFB stands for Multi-function Button

Modes

Press Up Arrow button 2 Times Quickly to Turn On Movie/Gaming mode.

Note: Movie/gaming mode will be Off by Default.

Power Off

Press MFB until Red LED light blinks & Turn Off.

Bluetooth Connectivity - Automatic

Just Turn On the Wireless Neckband. It will Automatically Connect to the Last Connected Device. **Note:** Last connected device must be in 10meters wireless range and Bluetooth must be On.

Instant Voice Assistant Activation

Long Press MFB for 2 seconds to Awake your Phone's Voice Assistant.

Call & Music Functions

Answer/Hangup a Phone Call: Press MFB Once Reject a Phone Call: Press MFB for 2 seconds Music Play/Pause: Press MFB Once Next Song: Long Press "Down Arrow" button Previous Song: Long Press "Up Arrow" button Volume Up: Press "Up Arrow" button Volume Down: Press "Down Arrow" button Re-dial: Press MFB Twice in Standby mode Mode Change: Press Up Arrow Twice quickly

Note: MFB stands for Multi-function Button

Charging the Neckband

 Turn Off the Neckband before Charging
Connect the Type-C End of the Charging cable to the Neckband 3. Connect the USB end of the Charging cable to a Power Source such as USB Charger or other Charging Devices of 5V Output

4. Red LED light will be Steady during Charge. Once the Neckband is Fully Charged, Red LED indicator will Turn Off

5. Un-plug Both the Ends of the Charging cable

Troubleshooting Scenario: Connectivity Issue

 Turn OFF the neckband and charge 100%
Unpair with the connected Bluetooth device
Restart the Bluetooth device
After 100% charging switch ON the neckband and pair it with the Bluetooth device again

Disclaimer

The colors and specifications shown/mentioned in the user manual may differ from the actual product. The images shown are for representation purposes only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.