- 3. Open the phone wireless function, search for wireless devices.
- 4. Select "pTron Twins Pro", Wireless earbud and mobile phone willl pair. If you are wearing the earbuds, you will hear a voice "Your phone is connected". When you disconnect the wireless connection, you will hear a voice "Your Phone is disconnected".
- 5. If the pairing succeeds, the blue indicator light flashes every 5 seconds. If the pairing fails, please repeat the above.

Method of Re-pairing (pTron Twins Pro):

Turn on both the earbuds same time, and the red and blue LED indicators on both sides will flash alternately. Then double-click on one of the power buttons. If the other side indicator is off, then pairing is successful.

Incomina Call

The earbuds will broadcast the incoming number. If you are wearing the earbuds, you will hear the incoming number and a voice "Incoming call". It is normal only one side of the incoming number and a voice "Incoming call". It is normal only one side of the earbuds has a sound when you are calling Low bottery alarm.

When the battery is low power, there will be a voice alarm inside "Battery low" every 30 seconds.

Considerations

- Don't use headset while driving, Please abide by the provisions of the country or region. Please do not overuse this headset or put it under heavy pressure, otherwise may cause headset failure or burned.
- 2. Do not use the equipment temperature too low or too high (below 0°C or above 45 0°C) environment. The extreme temperatures will lead to deformation of equipment, reduce the charge capacity of equipment and shorten the service life of equipment.
- Do not use the equipment to wet liquid can cause severe damage to equipment. Please do not use wet hand contact device, due to water damage caused by equipment, manufacturers will not be warranty.
- 4. Please do not use the equipment in thunderstrom weather. Thunderstroms can result in ill operation of the equipment and increase in the risk of electric shocks.

Disclaimer

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.





Twins Pro
Sports Wireless Earphones

Instruction Manual

Product Specifications

Connectivity: Advanced Wireless

Transmission Distance: Up to 10m (open space)

Frequency Range: 20Hz-20kHZ Speaker Size: 14.2 mm

Speaker Impedance: 32 Ohm

Speaker Power: 7mW

Mic. Sensitivity (Inbult): -42+2dB

Battery Capcity: 160mAh (each earphone 80mAh)

Music Playtime: Up to 4 Hours*

Talk time: 4 Hours*
Standby time: 200 Hours
Charge Time: 1.5 Hours
Material: PC/ABS



Key Operation Instructions

- Muti-function key: Long press for 3 seconds is turn on/off. Short press to play/pause. Click to answer the call, long press for 2 seconds to refuse the call. Quickly double-click twice to call the last number.

 Side values a key Long press to increase the values. Short Press to
- 2. Side volume + key: Long press to increase the volume. Short Press to switch the next song.
- 3. Side volume key: Long press to reduce the volume. Short press to switch the last song.

Earbuds Charging

The earbuds use a rechargeable battery and must be fully charged before using at first time.

- 1. The charger wire connected to the seat of the charging socket.
- 2. Insert the charger power switch.
- 3. The charging indicator light shows red, when fully charged, the light will turn blue.
- 4. Remove the charger from charging of power outlet.
- The charging is complete.
- 6. Please use the original charger.
- Note: The earbuds will be off when charging.

On/Off

Turn On: Long Press the multi-function key for 3 seconds until the red and blue lights alternately flash. If you are wearing the earbuds, you will hear a voice "Power on".

Turn off: Long press the multi-function key for 3 seconds, If you are wearing the earbuds, you will hear a voice "Power off".

Wireless Pairing Steps (single earbud mode)

- 1. When earbud is paired for the first time, keep the distance between the Wireless earbud and the phone in the range of 1 meter.
- 2. Press the "multi-function"key for 3 seconds, red and blue lights flash alternately.
- 3. Open the phone Wireless function, search for Wireless devices.
- 4. Select "pTron Twins Pro", Wireless earbud and mobile phone will pair.
- If you are wearing the earbuds, you will hear a voice "Your Phone is connected".

When you disconnect the Wireless connection, you will hear a voice "Your Phone is disconnected".

5. If the pairing succeeds, the blue indicator light flashes every 5 seconds. If the pairing fails, please repeat the above.

Wireless Pairing Step (Dual Earbuds)

- 1. Press the two earbuds "Multi-function" key for 3 seconds at the same time, red and blue lights flash alternately. These two earbuds will be paired automatically, one of the earbuds will flash red and blue lights alternately, the other one will flash blue every 5 seconds. If you are wearing the earbuds, you will hear a voice "Paired".
- 2. Keep the distance between the wireless earbuds and the phone in the range of 1 meter.