
Z-series Quick-Start Guide



Step 1: Fully Charge Battery

Slip safety covers off of battery terminals. Note that it's not necessary to remove battery wire harness. Attach charger to battery, plug charger in, and turn it on. Red light will illuminate when charger is powered on. Amber light will show when battery is charging and will turn green when battery is fully charged.



Step 2: Attach Drive Wheels

- Remove protective covers from main axle.
- On inside of drive wheels, locate and pull wheel tab.
- Place each wheel on axle, aligning drive pins on axle with holes in wheel panel.





Pulling wheel tab.

Inserting wheel on axle.

Step 3: Attach Steering Structure

- Open draw latch under battery tray.
- Insert steering structure into hole in front of battery tray and secure draw latch.
- Attach wire plug from steering structure to receptacle on Z-box as shown.



Steering Structure being inserted into chassis.



Plug in electrical connection to Z-box.

Step 4: Attach Handle Assembly

- Open draw latch on top of chassis.
- Insert handle assembly into hole and secure draw latch.
- Attach wire plug to receptacle on backside of Z-box.
- Remove three plastic tie-wrap bands from handle.



Attaching handle assembly to chassis.



Attaching wires.

Step 5: Manual Operation

Before putting your bag on caddie and hitting the links, practice using manual and remote operation.


- SET FUNCTION SWITCH TO OFF.
- Place battery on battery tray and plug battery wire harness into the chassis power port.
- Manual Operation: Set speed control at white line (slow), set the function switch to MANUAL, and slowly increase speed.



Connecting the battery.



Function Switch



Speed Control

Step 6: Remote Control

- To use remote control mode, toggle function switch to REMOTE and set speed control to desired setting.
- GO: Caddie will travel at set speed.
- FAST: Caddie will travel at top speed. Press GO to return to set speed.
- LEFT (Looking from behind caddie): Front wheel will turn left. Releasing button re-centers wheel.
- RIGHT (Looking from behind caddie): Front wheel will turn right. Releasing button centers wheel.
- STOP (Looking from behind caddie): Caddie will stop. Red light blinks to confirm command.

For safety reasons, caddie will automatically shut off if no command is given within 20 seconds.



Step 7: Load Your Golf Bag

Upper bag support is adjustable. Secure bag with strap and buckle.

Go Play Golf!



Contact Timothy Bame



If you have any questions about your Z-series,
Timothy Bame at our factory in Columbus,
North Carolina will be glad to help you.

800-438-3011 or 828-436-2101 Monday-Friday 8am – 5pm Eastern Time

Email: Zseries@kangaroogolf.com or iwalk@kangaroogolf.com

Kangaroo Golf 111 Kangaroo Drive Columbus, NC 28722 www.KangarooGolf.com