IGX-450S User Manual

|		
🇬🇧	For more instructions in English please visit:	www.igadgitz.com /guides
🇩🇪	Eine Anleitung in Deutsch finden Sie unter:	
🇪🇸	Para obtener instrucciones en Español por favor visite:	
🇫🇷	Pour obtenir des instructions en français s'il vous plaît aller à:	
🇮🇹	Per istruzioni in italiano si prega di visitare il sito:	

www.igadgitz.com

FC CE ♻

Product Overview

1. Multi-functions button (**MFB**)
2. Volume up /Previous song
3. Volume down /Next song
4. Microphone
5. Micro USB charging jack

Box Contents

Bluetooth Stereo Earphones (IGX-450S)
USB Charging Cable
3 Pairs of Silicone Ear Tips (S,M,L)
3 Pairs of Secure Fit Fins (S,M,L)
Carry Case

Turning On | Off

Functions	Operation
Turning on	Press and hold **MFB** for 4 seconds until Blue LED flashes
Turning off	Press and hold **MFB** button about 4 seconds until Red LED flashes

Charging

iGadgitz IGX-450S comes with a built-in rechargeable battery. Prior to using it, it is recommended to charge the battery fully for the first time. When IGX-450S is low in power it emits prompt tones every 5 minutes and the red LED flashes. Please recharge the battery as soon as possible.

1. Plug USB cable into a PC/Laptop USB port or suitable 5.0V USB power charger
   - Red light on: Charging
   - Red light off: Finished charging
2. It takes around 2 hours to fully charge. Do not charge for longer than 2.5 hours or battery life will be damaged.

**IMPORTANT WARNING: Do not connect to a PC or USB charger if damp or wet. Danger of electrocution.
If becomes very hot during charging or emits smoke/vapour; switch off at the plug socket, disconnect, do not use and contact your retailer.**

Please Note: The battery is recyclable.
Batteries (battery pack or batteries installed) should not be exposed to excessive heat, fire, water or high voltage equipment.

Pairing | Connecting

The general pairing procedures are as follows, however, you may need to refer to your Bluetooth device's manual on how to pair with a Bluetooth device.

1) Keep your Bluetooth enabled device within 1 metre when pairing;
2) Make IGX-450S enter pairing mode as shown below:

Function	Operation
Entering pairing mode	Ensure IGX-450S is off. Press and hold **Multi-Function Button** for approximately 8 seconds until Red and Blue LED flash rapidly

3) Using your Bluetooth device, scan/search for available Bluetooth devices. Select "IGX-450S" from the list of devices shown;
4) If prompted, enter password or PIN No: "0000"
5) If prompted by your device to connect, select "Yes" (this will vary among devices)
6) After successfully connecting, the Blue LED of the earphones will flash twice every 4 seconds

Please Note:

Pairing mode will last 2 minutes. If no devices can be connected after 2 minutes, it will return to standby mode automatically.

If pairing is failed, please turn off IGX-450S first and then re-pair according to steps 1~6 mentioned above.

After pairing is successful, IGX-450S and the Bluetooth device will remember each other and should not need to be re-paired next time. IGX-450S can store 8 paired devices. When the number of paired devices exceeds this, the first one will be replaced.

Each time IGX-450S is turned on, it will connect automatically to last connected device. If you want to pair it with other devices, please turn off the Bluetooth function of the last connected device first and pair IGX-450S with the new device.

Hands Free Function

The built-in microphone in IGX-450S allows you to answer and end calls.
Please use the chart below to execute your desired function.

Functions	IGX-450S Status	Operation
Cancel a call	Calling	Short press MFB once
Answer a call	Incoming ringing	Short press MFB once
Reject a call	Incoming ringing	Long press MFB about 2 seconds until you hear a tone
End a call	During a call	Short press MFB once
Redial last number	Standby mode (connected device)	Double click MFB
Call transfer(headset to phone)	During a call	Press and hold MFB for 2 seconds
Call transfer(phone to headset)	During a call	Press and hold MFB for 2 seconds
Microphone mute	During a call	Double click MFB
Cancel mute	During a call	Double click MFB

Pair with a Bluetooth Transmitter

You can connect IGX-450S to a Bluetooth transmitter to enjoy music wirelessly. The pairing steps are as follows:

1. Place IGX-450S and the Bluetooth transmitter where they are easily viewable by no more than 1 metre apart
2. Switch IGX-450S to pairing mode
3. Turn on the Bluetooth transmitter. It will search for Bluetooth devices automatically and send a pairing request
4. When IGX-450S requests to enter a PIN, the transmitter will respond "0000" automatically
5. After successfully pairing and connecting, the Blue LED of IGX-450S flashes twice every 4 seconds

Notes:
• The pairing password of IGX-450S is "0000". IGX-450S can only pair with a Bluetooth transmitter whose pairing password is "0000".
• If pairing still fails after several times, please refer to the Bluetooth transmitter's user manual for further information.

Multi-pairing

IGX-450S can connect with two Bluetooth cell phones at the same time. The general pairing procedures are as follows:

1）Pair IGX-450S with device A

2）Turn on IGX-450S and make it enter pairing mode again, and pair it with device B

3）Operate device A to connect with headset. IGX-450S has now connected with two devices

Three-way call

Functions	Status of headsets	Operation
Answer new call and retain current call	There is a new incoming call	Short click MFB once
Switch calls	During a call	Double click MFB
End current call and switch to held call	Keep conversation	Short press MFB once

Notes:

• Not all mobile phones support all functions listed above. Please refer to your mobile phone's user manual for further information.
• Certain functions and indication tones may vary with different models of phone.
• When the volume is adjusted to max. or min., you will hear an indication tone.
• When pressing the answer button on some mobile phones, the call will be transferred to the phone. You will have to switch the call to IGX-450S manually. Please refer to your mobile phone's user manual for further information.

Music Functions

While you are listening to music, you can control your Bluetooth device with the actions below on your IGX-450S earphones

Functions	IGX-450S Status	Operation
Volume up	Playing music	Short press "+" button
Volume down	Playing music	Short press "—" button
Previous song	Playing music	Long press "+" button
Next song	Playing music	Long press "—" button
Pause	Playing music	Short press MFB once
Play	Pausing	Short press MFB once

Specification and technical parameters

Bluetooth version	Bluetooth V4.0, APT-X supported
Bluetooth profiles	Headset, Hands free, A2DP, AVRCP
Operating distance	10 metres
Headset music time	Approx. 4.5 hours
Headset talk time	Approx. 4.5 hours
Headset standby time	Approx. 180 hours
Charging input	DC5.0V ===60mA
Headset charging time	Approx. 2 hours
Dimension	40*24*32mm
Weight	Approx. 16.4g
Battery capacity	80mAH

Factory Reset

Please note: On rare occasions you may need to perform a factory reset.

When charging your earphones, simply long press the volume up "+" button for about 4 seconds and release it when the red and blue LED flashes simultaneously. You will hear 4 "dong" tones.

Maintenance, Care & Safety

Users are not permitted to make changes or modify the product and accessories in any way

1. DO NOT use the product while operating a motor vehicle.
2. To avoid electronic interference and/or compatible conflicts, TURN OFF the product in any facilities where posted notices instruct you to do so. For example: Aircraft, Military Base, Hospital or Health Care Facilities.
3. To avoid impairing your hearing, keep the headset volume at a moderate level. Do not listen at high volumes for prolonged periods. Check volume before placing in ear.
4. Take care to not insert the earphone too far into the ear canal.
5. For your safety, avoid distractions from music or phone calls while in public places or potentially dangerous environments.
6. Keep away from fire, water, and high voltage equipment.
7. Do not install, place or use the headset near any source of heat such as a cooker, radiator, oven, toaster, coffee maker or other apparatus (including microwave ovens) that gives off heat.
8. It is recommended to keep the environment temperature between 15°C & 25°C
9. Follow the charging procedure in this guide to charge the product.

10. Do not use chemicals or detergents to clean the product.
11. IGX-450S is sweat proof to a degree but should not be submerged or exposed to water. Do not charge if damp or wet. Ensure fully dry before charging.
12. If becomes very hot during charging or emits smoke/vapour; switch off at the plug socket, disconnect, do not use and contact your retailer.

igadgitz