

IGX-470S User Manual



	For more instructions in English please visit:	www.igadgitz.com /guides 
	Eine Anleitung in Deutsch finden Sie unter:	
	Para obtener instrucciones en Español por favor visite:	
	Pour obtenir des instructions en français s'il vous plaît aller à:	
	Per istruzioni in italiano si prega di visitare il sito:	


www.igadgitz.com



Product Overview

Please fully read the manual before use

1. Multi-functions button (MFB)
2. Volume up /Next song
3. Volume down /Previous song
4. Microphone
5. Micro USB charging jack



Box Contents

Bluetooth Stereo Earphones (IGX-470S)

USB Charging Cable

3 Pairs of Silicone Ear Tips (S,M,L)

2 Pairs of Secure Fit Fins (S,M)

1 Pair of Clip-on Ear Hooks

Carry Case

Turning On | Off

Functions	Operation
Turning on	Press and hold MFB for 3 seconds until Blue LED flashes "power on"
Turning off	Press and hold MFB button about 5 seconds until Red LED flashes "power off"

Charging

iGadgitz IGX-470S comes with a built-in rechargeable battery. Prior to using it, it is recommended to charge the battery fully for the first time. When IGX-470S is low in power it emits prompt tones every 3 minutes and the red LED flashes. Please recharge the battery as soon as possible.

1. Plug USB cable into a PC/Laptop USB port or suitable 5.0V USB power charger
 - Red light on: Charging
 - Blue light on: Finished charging
2. It takes around 2 hours to fully charge. Do not charge for longer than 2.5 hours or battery life will be damaged.

IMPORTANT WARNING: Do not connect to a PC or USB charger if damp or wet. Danger of electrocution. If becomes very hot during charging or emits smoke/vapour or liquid; switch off at the plug socket, disconnect, do not use and contact your retailer.

Batteries (battery pack or batteries installed) should not be exposed to excessive heat, fire, water or high voltage equipment. The battery is recyclable.



Pairing | Connecting

The general pairing procedures are as follows, however, you may need to refer to your Bluetooth device's manual on how to pair with a Bluetooth device.

- 1) Keep your Bluetooth enabled device within 1 metre when pairing;
- 2) Make IGX-470S enter pairing mode as shown below:

Function	Operation
Entering pairing mode	Ensure IGX-470S is off. Press and hold Multi-Function Button for approximately 7 seconds until Red and Blue LED flash rapidly "power on...pairing"

- 3) Using your Bluetooth device, scan/search for available Bluetooth devices. Select "IGX-470S" from the list of devices shown;
- 4) If prompted, enter password or PIN No: "0000"
- 5) If prompted by your device to connect, select "Yes" (this will vary among devices)
- 6) After successfully connecting, the Blue LED of the earphones will flash once every 6 seconds "connected"

Please Note:

Pairing mode will last 3 minutes. If no devices can be connected after 3 minutes, it will return to standby mode automatically.

If pairing fails, please turn off IGX-470S first and then re-pair according to steps 1~6 mentioned above. Restart your device if pairing is still unsuccessful.

After pairing is successful, IGX-470S and the Bluetooth device will remember each other and should not need to be re-paired next time. IGX-470S can store 8 paired devices. When the number of paired devices exceeds this, the first one will be replaced.

Each time IGX-470S is turned on, it will connect automatically to last connected device. If you want to pair it with other devices, please turn off the Bluetooth function of the last connected device first and pair IGX-470S with the new device.

Voice notification settings:**Turn on the Voice Notification**

Entering the pairing mode, press the button (2) “+” for 3 seconds, the blue LED flashes 3 times.

Turn off the Voice Notification

Entering the pairing mode, press the button (3) “-” for 3 seconds, the red LED flashes 3 times.

Hands Free Function

The built-in microphone in IGX-470S allows you to answer and end calls. Please use the chart below to execute your desired function.

Functions	IGX-470S Status	Operation
Cancel a call	Calling	Short press MFB once
Answer a call	Incoming ringing	Short press MFB once
Reject a call	Incoming ringing	Double click MFB
End a call	During a call	Short press MFB once
Redial last number	Standby mode (connected device)	Double click MFB
Call transfer(headset to phone)	During a call	Press and hold MFB for 2 seconds
Call transfer(phone to headset)	During a call	Press and hold MFB for 2 seconds
Mic mute	During a call	Double click MFB
Cancel mute	During a call	Double click MFB

Pair with a Bluetooth Transmitter

You can connect IGX-470S to a Bluetooth transmitter to enjoy music wirelessly. The pairing steps are as follows:

1. Place IGX-470S and the Bluetooth transmitter where they are easily viewable by no more than 1 metre apart
2. Switch IGX-470S to pairing mode
3. Turn on the Bluetooth transmitter. It will search for Bluetooth devices automatically and send a pairing request
4. If IGX-470S requests to enter a PIN, the transmitter will respond "0000" automatically
5. After successfully pairing and connecting, the Blue LED of IGX-470S flashes once every 6 seconds

Notes:

- The pairing password of IGX-470S is "0000". IGX-470S can only pair with a Bluetooth transmitter whose pairing password is "0000".
- If pairing still fails after several times, please refer to the Bluetooth transmitter's user manual for further information.

Multi-pairing

IGX-470S can connect with two Bluetooth cell phones at the same time. The general pairing procedures are as follows:

- 1) Pair IGX-470S with device A, switch off IGX-470S
- 2) Turn on IGX-470S and enter pairing mode again, and pair it with device B
- 3) Operate device A to connect with headset. IGX-470S has now connected with two devices

Three-way call operation

Functions	Status of headsets	Operation
Answer new call and retain current call	There is a new incoming call	Short click MFB once
Switch calls	During a call	Short click MFB once

Notes:

- Not all mobile phones support all functions listed above. Please refer to your mobile phone's user manual for further information.
- Certain functions and indication tones may vary with different models of phone.
- When the volume is adjusted to max. or min., you will hear an indication tone.
- When pressing the answer button on some mobile phones, the call will be transferred to the phone. You will have to switch the call to IGX-470S manually. Please refer to your mobile phone's user manual for further information.

Music Functions

While you are listening to music, you can control your Bluetooth device with the actions below on your IGX-470S earphones

Functions	IGX-470S Status	Operation
Volume up	Playing music	Short press “+” button
Volume down	Playing music	Short press “-” button
Previous song	Playing music	Long press “-” button
Next song	Playing music	Long press “+” button
Pause	Playing music	Short press MFB once
Play	Pausing	Short press MFB once

Specification and technical parameters

Bluetooth version	Bluetooth v4.1, APTX supported
Bluetooth profiles	Headset, Hands free, A2DP, AVRCP
Operating distance	10 metres
Headset music time	Approx. 5 hours
Headset talk time	Approx. 6 hours
Headset standby time	Approx. 180 hours
Charging input	DC5.0V $\overline{=}$ 60mA
Headset charging time	Approx. 2 hours
Dimension	40*24*32mm
Weight	Approx. 16g
Battery capacity	85mAH

Factory Reset

Please note: On rare occasions you may need to perform a factory reset.

When charging your earphones, simply long press the MFB button for about 4 seconds and release it when the purple LED flashes 3 times.
(Red and Blue LED flash simultaneously=purple LED)

NOTE: The headset automatically powers down (off) when you charge it. If you try to turn the headset back on during charging, you will hear two beeps. The headset will go to default setting, that means you have to 'forget the IGX-470S' on your device and then pair them again.

Maintenance, Care & Safety

Users are not permitted to make changes or modify the product and accessories in any way

1. Fully read the manual before use.
2. DO NOT use the product while operating a motor vehicle.
3. To avoid electronic interference and/or compatible conflicts, TURN OFF the product in any facilities where posted notices instruct you to do so. For example: Aircraft, Military Base, Hospital or Health Care Facilities.
4. To avoid impairing your hearing, keep the headset volume at a moderate level. Do not listen at high volumes for prolonged periods. Check volume before placing in ear.
5. Take care to not insert the earphone too far into the ear canal.
6. For your safety, avoid distractions from music or phone calls while in public places or potentially dangerous environments.
7. Keep away from fire, water, and high voltage equipment.
8. Do not install, place or use the headset near any source of heat such as a cooker, radiator, oven, toaster, coffee maker or other apparatus (including microwave ovens) that gives off heat.

9. It is recommended to keep the environment temperature between 0°C & 40°C
10. Follow the charging procedure in this guide to charge the product.
11. Do not use chemicals or detergents to clean the product.
12. IGX-470S is sweat proof to a degree but should not be submerged or exposed to water. Do not charge if damp or wet. Ensure fully dry before charging.
13. If becomes very hot during charging or emits smoke/vapour; switch off at the plug socket, disconnect, do not use and contact your retailer.

igadgitz



FC CE 