



BLUETOOTH SPEAKER USER GUIDE FOR:

The Cube



Mic Idol



Volcano



FC CE
made in China

Specification and technical parameters

Rated Power: 3W
Battery: Built-in Li-Polymer Rechargeable (400mAh)
Operating temperature: 10°C - 25°C
Performance: Bluetooth Specification V3.0, up to 10 meters (in open space)
Operating distance: 10m (33 ft)
Music/Talk time: 4 hours*
Charging time: 1 hour
Charging Input: DC5.0V 350mA
Dimensions/weight:
Mic Idol: 82x82x82mm; 275g
Volcano: 80x80x80mm; 320g
The Cube: 46x46x46mm; 138g

*The maximum operating time depends on the usage frequency and environmental factors. A long distance wireless connection and use with a mobile phone will increase the power consumption.

Fit for:



Safety and General Information

Please read the following information before using this product.

- Do not use the product while operating a motor vehicle.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so. For example: On aircraft, Military Bases, Hospitals or Health Care Facilities.
- To avoid impairing your hearing, keep the speaker volume at a moderate level. Do not listen at high volumes for prolonged periods. Check volume before turning on.
- For your safety, avoid distractions from music or phone calls while in public places or potentially dangerous environments.

- Keep away from fire, and high voltage equipment.
- Do not install, place or use the speaker near any source of heat such as a cooker, radiator, oven, toaster, coffee maker or other apparatus (including microwave ovens) that gives off heat. Do not use in direct sunlight.
- It is recommended to keep the environment temperature between 15°C & 25°C
- Follow the battery and charging procedure in this guide to charge the product.
- Do not use chemicals or detergents to clean the product.
- The speaker should not be submerged or exposed to water. Do not charge if damp or wet. Ensure fully dry before charging.

IMPORTANT WARNING: Do not connect to a PC or USB charger if speaker is damp or wet. Danger of electrocution.

Battery and Charging Procedure

- The product uses a rechargeable battery. A normal charging process takes about 1 hour. The red LED will turn on when charging and will turn off when charging is finished. Do not charge for longer than 1.5 hours. This will shorten the lifetime of the battery.
- Plug the USB cable into a PC/Laptop USB port or suitable 5.0V USB power charger. Using any incorrect power supply device will cause damage and void the warranty.
- Should the unit become hot to touch during charging or emit smoke/vapour, switch off at the mains, disconnect and do not use. Then contact your retailer.
- After charging has finished, please remove the cable from the speaker. Do not charge the speaker for long periods of time.

- Please make sure the battery has been fully charged and fully discharged for the first three uses to ensure optimum battery performance.
- Do not use the speaker in too hot or too cold environments. It is recommended to keep the environment temperature between 15°C and 25°C.
- Do not connect, place or use the speaker near any source of heat such as a cooker, radiator, oven, toaster, coffee maker or other apparatus (including microwave ovens) that gives off heat. Do not use in direct sunlight.

IMPORTANT WARNING: Do not connect to a PC or USB charger if speaker is damp or wet. Danger of electrocution.

For More Instructions

For more instructions in English please visit:

Eine Anleitung in Deutsch finden Sie unter:

Para obtener instrucciones en Español por favor visite:

Pour obtenir des instructions en Français s'il vous plait aller à:

Per istruzioni in Italiano si prega di visitare il sito:

www.igadgitz.com/guides




The Cube

1. Power on/off




Slide Button

2. Recharging




Recharge your speaker using a Micro USB cable from a compatible device.

3. Bluetooth Connection




Go to the bluetooth settings of your device and select 'Xquare 2'

4. Configuration



Mic Idol

1. Configuration



2. Configuration Continued



3. Bluetooth Connection



Go to the bluetooth settings of your device and select 'iDol 2'

4. Volume & Play/Pause Adjustment




5. Recharging



Recharge your speaker using a Micro USB cable from a compatible device.

Volcano

1. Configuration



Volume - twist clockwise
Volume + twist anti-clockwise

2. Configuration Continued



Recharge your speaker using a Micro USB cable from a compatible device.

3. Bluetooth Connection



Go to the bluetooth settings of your device and select 'Volcano 2'

4. Volume & Play/Pause Adjustment



5. Recharging



Recharge your speaker using a Micro USB cable from a compatible device.

igadgitz™ is a registered trademark of INNOV8 GB Ltd. All rights reserved. Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by the manufacturer is under license. Other trademarks and trade names are those of their respective owners.