

Pop-Up Banner Displays

SKU:
POPT470
POPC395
POPTB4079
POPH4728
POPV2436

Comes with Ground Pegs and Carry Case.

Pops Open in Seconds!



Take out the Pop-Up frame from the carry bag. The graphical fabric is already installed to the frame.

1




Pop out the graphic frame to show the banner.

2



Connect the hook-and-loop fasteners on both ends.

3



Repeat to connect the hook-and-loops on the bottom part of the frame.

4



Your Pop-Up Banner Display is ready for showcase! Perfect to display indoors and outdoors. *Use ground stakes when using the stand on soft surfaces such as grass, sand, snow, or soil to keep it in place.

5

***WHEN DONE**
 Fold the banner back to its flat size by bringing the 2 panels together, folding horizontally. Then keep a firm grip in the middle of the frame with both hands and proceed to pull the 2 sides together while processing top of the Pop-Up down. After that, keep a firm grip and twist the top of the upper panel over the middle and fold the outer section underneath the middle of the upper panel. Finally, adjust the 3 panels until they are even and hold tightly. Quickly place the Pop-Up in the carrying bag and zip the bag to complete.

6