

# 15+ CHALLENGER HEADLIGHT INTAKE RING

INSTULATION DIFFICULTY .01/5

## TOOLS NEEDED

- YOURSELF
1. USE BOTH HANDS TO SPIN AND PULL OUTWARD ON INTAKE RING TO REMOVE
  2. CAREFULLY PRESS IN NEW RING
  3. ENJOY THE NEW AND IMPROVED LOOK